



บริษัท เอดีดี เฟอร์เนส จำกัด

ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

<https://www.add-furnace.com> E-mail: [sales@add-furnace.com](mailto:sales@add-furnace.com)

# SIEMENS



## RWF55.5 and RWF55.6

### Compact universal controllers

Optimized for temperature and pressure control in connection with modulating or multistage burners and air conditioning systems

### User Manual

The RWF55.5/RWF55.6 and this User Manual are intended for use by OEMs which integrate the controllers in their products!



**Caution!**

All safety, warning and technical notes contained in the Data Sheet on the RWF55 (N7867) also apply to this document!

CC1U7867en  
01.09.2017

Building Technologies Division  
Infrastructure & Cities Sector



บริษัท เอดีดี เฟอร์เนส จำกัด

ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

<https://www.add-furnace.com> E-mail: [sales@add-furnace.com](mailto:sales@add-furnace.com)



บริษัท เอดีดี เฟอร์เนส จำกัด

ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

<https://www.add-furnace.com> E-mail: [sales@add-furnace.com](mailto:sales@add-furnace.com)

## Supplementary documentation

Data Sheet RWF55 .....	N7867
Environmental Declaration RWF55 .....	E7867



บริษัท เอดีดี เฟอร์เนส จำกัด

ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

<https://www.add-furnace.com> E-mail: [sales@add-furnace.com](mailto:sales@add-furnace.com)



## Contents

1	Introduction.....	8
1.1	General notes .....	8
1.2	Typographical conventions .....	9
1.2.1	Safety notes.....	9
1.2.2	Warning symbols .....	9
1.2.3	Notification symbols.....	10
1.2.4	Presentation .....	10
1.3	Description.....	11
1.4	Block structure.....	12
2	Identification of product no. ....	13
2.1	Type field .....	13
2.2	Scope of delivery .....	13
3	Installation .....	14
3.1	Installation site and climatic conditions.....	14
3.2	Dimensions.....	14
3.3	Side-by-side mounting.....	15
3.4	Mounting the controller in a panel cutout.....	15
3.5	Removing the controller from the panel cutout.....	16
3.6	Cleaning the front .....	16
4	Electrical connections.....	17
4.1	Installation notes.....	17
4.2	Galvanic separation .....	18
4.3	Assignment of terminals .....	19
5	Operating modes .....	22
5.1	Low-fire operation.....	22
5.2	High-fire operation .....	23
5.2.1	Modulating burner, 3-position output .....	23
5.2.2	Modulating burner, analog output.....	24
5.2.3	2-stage burner, 3-position output.....	25
5.2.4	2-stage burner, analog output .....	26
5.3	Burner shutdown .....	27
5.4	Predefined setpoint.....	28
5.4.1	Setpoint changeover SP1 / SP2 or setpoint shift analog via InP2 .....	29
5.4.2	Setpoint changeover SP1 / external setpoint via InP2.....	30
5.4.3	Setpoint shifting SP1 analog via InP2 / binary via dSP .....	31



5.4.4	External setpoint, setpoint shifting binary via dSP.....	32
5.5	Weather-compensated setpoint shifting .....	33
5.6	Response threshold (q) .....	34
5.7	Cold start of plant .....	35
5.8	Thermal shock protection (TSS).....	37
6	Operation.....	38
6.1	Meaning of display and buttons.....	38
6.2	Basic display .....	40
6.3	User level .....	41
6.4	Manual control, modulating burner.....	42
6.5	Manual control, 2-stage burner .....	43
6.6	Starting the self-setting function .....	44
6.7	Display of software version .....	45
7	Parameterization PArA.....	46
8	Configuration ConF .....	49
8.1	Analog input InP1 .....	50
8.2	Analog input InP2 .....	52
8.3	Analog input InP3 .....	53
8.4	Controller Cnt r .....	54
8.5	Thermal shock protection (TSS) rAFC .....	55
8.6	Alarm function AF.....	56
8.7	Control outputs OutP .....	58
8.8	Binary input bi nF .....	59
8.9	Display diSP .....	60
8.10	Interface Int F.....	61
9	Self-setting function.....	62
9.1	Self-setting function in high-fire operation .....	62
9.2	Checking the controller parameters .....	64
10	PC software ACS411 .....	65
10.1	Safety notes .....	65
10.2	Setting the correct system parameters.....	65
10.3	Changing the parameters or the plant's configuration.....	65
10.4	Place of installation .....	66
10.5	License and liability regulations.....	66
	IMPORTANT – PLEASE READ CAREFULLY! .....	66
10.6	Procurement of PC software ACS411 .....	66
10.7	Languages .....	66
10.8	Operating systems : Operating.....	66



10.9	Prerequisites for hardware .....	66
10.10	Installation .....	67
10.11	Others.....	67
10.11.1	Use of USB port : Use of .....	67
10.11.2	Powering the controller via the USB port : Powering the controller via the port .....	67
11	Modbus interface .....	68
11.1	User level.....	68
11.2	Parameter level .....	69
11.3	Configuration level.....	70
11.4	Remote operation .....	70
11.5	Device data.....	71
11.6	Device state.....	71
12	Profibus-DP interface .....	72
12.1	RS-485 Technology transfer.....	72
12.2	Wiring .....	77
12.3	Parameter list .....	77
13	What to do if .....	78
13.1	Alarm messages:.....	78
13.2	Others.....	78
14	Technical data .....	79
14.1	Inputs.....	79
14.1.1	Analog input I nP1 (actual value).....	79
14.1.2	Analog input I nP2 (external setpoint, setpoint shifting).....	81
14.1.3	Analog input I nP3 (outside temperature).....	81
14.1.4	Binary input D1 .....	81
14.1.5	Binary input D2 .....	82
14.2	Monitoring the measuring circuit.....	83
14.3	Controller outputs Out P .....	84
14.4	Controller .....	85
14.5	Electrical data .....	85
14.6	Housing .....	85
14.7	Environmental conditions .....	86
14.8	Segment display .....	86
14.9	Standards and certificates .....	87
15	Key .....	88
16	List of figures .....	90



# 1 Introduction

---

## 1.1 General notes



Please read this User Manual before switching on the controller. Keep the User Manual in a safe place which can be accessed by all users at all times.



Version!

This User Manual describes all necessary settings (applicable to controller software version XXX.01.01).



Reference!

See chapter 6.7 *Display of software version*.





## 1.2 Typographical conventions

### 1.2.1 Safety notes

This User Manual contains information which must be observed to ensure your own personal safety and to prevent damage to equipment and property. The instructions and notes are highlighted by warning triangles, a hand or arrow symbol and are presented as follows, depending on the hazard level:

#### Qualified personnel

Only **qualified personnel** are allowed to install and operate the equipment. Qualified personnel in the context of the safety-related notes contained in this document are persons who are authorized to commission, ground and tag devices, systems and electrical circuits in compliance with established safety practices and standards.

#### Correct use

Note the following:

The controller may only be used on the applications described in the technical documentation and only in connection with devices or components from other suppliers that have been approved or recommended by Siemens.

The product can only function correctly and safely if shipped, stored, set up and installed correctly, and operated and maintained as specified.

### 1.2.2 Warning symbols

The symbols for **Caution** and **Attention** are used in this User Manual under the following conditions:



#### Caution

This symbol is used where there may be a **danger to personnel** if the instructions are disregarded or not strictly observed!



#### Attention

This symbol is used where **damage to equipment or data** can occur if the instructions are disregarded or not strictly observed!






#### Attention



This symbol is used if **precautionary measures must be taken** when handling electrostatically sensitive components.



### 1.2.3 Notification symbols

	<b>Note</b>	This symbol is used to draw your <b>special attention</b> to a remark.
	<b>Reference</b>	This symbol refers to <b>additional information</b> in other documents, chapters or sections.
abc <sup>1</sup>	<b>Footnote</b>	Footnotes are <b>comments, referring to specific parts of the text</b> . They consist of 2 parts: 1) <b>Markings</b> in the text are arranged as continuous superscript numbers 2) <b>Footnote text</b> is placed at the bottom of the page and starts with a number and a period
*	<b>Action</b>	An asterisk indicates that a <b>required action</b> is described.  The individual steps are indicated by asterisks, for example:  * Press 

### 1.2.4 Presentation

	<b>Buttons</b>	Buttons are shown in a circle. Either symbols or text are possible. If a button has multiple assignments, the text shown is always the text corresponding to the function currently used.
	<b>Button combinations</b>	Two buttons shown in combination with a plus sign means that they must be pressed simultaneously.
ConF → InP → InP1	<b>Command chain</b>	Arrows between words serve for finding parameters at the configuration level more easily or for navigating in the ACS411 setup program.



## 1.3 Description

### Use in heating plants

The RWF55 is used primarily for the control of temperature or pressure in oil- or gas-fired heating plants. Depending on the setting, it is employed as a compact 3-position controller or as a modulating controller with an analog output. An external switch is provided to convert it to a 2-position controller for controlling 2-stage burners. The built-in thermostat function switches the burner on and off.

### Cooling controller

The controller's operating mode can be changed from heating to cooling, or vice versa.

⇒ Reference!  
See chapter 8.4 *Controller Cntr.*

### RWF55

The controllers feature two 4-digit 7-segment displays for the actual value (red) and the setpoint (green).

The RWF55 has a 3-position output consisting of 2 relays to open or close a controlling element.

There is also an analog output and a multifunctional relay (K6), which can be used to set 12 different switching functions.

### Interface

The controllers feature an RS-485 interface Modbus slave as standard.

### Option

Additionally, the RWF55.6 features a Profibus DP interface.

### Control

In modulating mode, the RWF55 operates as a PID controller. In 2-stage mode, the RWF55 provides control based on the set switching threshold.

You have the option of specifying the setpoint of the RWF55 on the controller or externally via an interface.

The user uses it for control the temperature or pressure of a heating boiler or cooling system.

It is possible to adjust the minimum and maximum setpoint limits.

2 binary inputs are used to execute functions such as setpoint changeover, setpoint shifting or operating mode changeover.


Standard feature is a self-setting function used to determine the PID control parameters.

### Mounting

The controller insert measures 48 x 96 x 122 mm and is especially suited for installation in control panels. All electrical connections are made via screw terminals at the rear of the unit.



### 1.4 Block structure



7867d01e/0313

Figure 1: Block structure




## 2 Identification of product no.

### 2.1 Type field

Location:

The type field is glued onto the housing. The arrow below indicates the product no.

Example



#### Attention!

Mains supply must correspond to the operating voltage given on the type field.

Product nos. :

Product no.	Description
RWF55.50A9	Full version with 3-position output, analog output, RS-485 – single pack
RWF55.51A9	Full version with 3-position output, analog output, RS-485 – multipack (20 pieces)
RWF55.60A9	Full version with 3-position output, analog output, RS-485 Profibus-DP – single pack
RWF55.61A9	Full version with 3-position output, analog output, RS-485 Profibus-DP – multipack (20 pieces)

### 2.2 Scope of delivery

- Type of controller as ordered
- User Manual (only single pack)



## 3 Installation

### 3.1 Installation site and climatic conditions

- The installation site should be free from vibrations, dust and corrosive media
- The controller should be installed away from sources of electromagnetic fields, such as variable speed drives or high-voltage ignition transformers

Relative humidity:  $\leq 95\%$  (noncondensing)

Ambient temperature:  $-20 \dots 50$  °C

Storage temperature:  $-40 \dots 70$  °C

### 3.2 Dimensions




Figure 2: Dimensions of RWF55

Key

- (1) USB interface setup
- (2) Panel cutout

### 3.3 Side-by-side mounting

If several controllers are mounted side-by-side or above one another in a control panel, the horizontal distance between panel cutouts must be a minimum of 11 mm and the vertical distance a minimum of 50 mm.

### 3.4 Mounting the controller in a panel cutout

- \* Remove the mounting clips
- \* Fit the seal supplied with the controller



#### Attention!

The controller must be installed with the seal, preventing water or dirt from entering the housing!




Figure 3: Mounting in a panel cutout

- \* Insert the controller from the front into the panel cutout (1) and make certain the seal is correctly fitted
- \* Working from the rear side of the panel, push the mounting clips into the guide slots on the side of the controller (2) and tighten them evenly using a screwdriver (3) until the controller housing is seated firmly in the panel cutout.



### 3.5 Removing the controller from the panel cutout



**Attention!**

When removing the controller, make certain that all cables are disconnected and that they do not get squeezed between control panel and housing.

### 3.6 Cleaning the front

The front of the controller can be cleaned with normal washing/rinsing agents or detergents.



**Attention!**

The front of the controller is **not** resistant to corrosive acids, caustic solutions and abrasive cleaners. Do not clean with high-pressure cleaners!





## 4 Electrical connections

### 4.1 Installation notes

#### Safety regulations

- The choice of cable, installation and electrical connections of the controller must conform to VDE 0100 *Regulations for the installation of power circuits with nominal voltages below AC 1000 V*, or the relevant local regulations
- The electrical connections must be made by qualified personnel
- If contact with live parts is possible while working on the unit, the controller must be disconnected from power supply (all-polar disconnection)
- When connecting the RWF55 to an external PELV circuit, the existing internal SELV circuit becomes a PELV circuit.  
The protection against electric shock hazard through double or reinforced insulation and voltage limitation is still present.  
No connection to protective earth is required.
- Equipment connected to the SELV circuit must have a safe separation from dangerous contact voltages in accordance with DIN EN 61140 (e.g. through double or reinforced insulation in accordance with DIN EN 60730-1).

#### Connection of external components



##### Caution!

When connecting external components to the safety extra low-voltage inputs or outputs of the RWF55 (terminals 11, 12, 13, 14, 21, 22, 23, 31, 32, D1, D2, DG, G+, G-, A+, A- and USB port, RS-485- and Profibus interface), it must be made certain that no dangerous active voltage are introduced to the RWF55. This can be achieved by using capsulated components with double/reinforced insulation or SELV components, for example. If not observed, there is a risk of electric shock.

#### Screw terminals



##### Caution!

All screw terminals at the rear of the unit must always be properly tightened. This applies to unused terminals as well.

#### Fusing



##### Caution!

- Fusing on site must not exceed 20 A
- The fuse on the controller side (AC 250 V/1.6 A slow) conforms to IEC 60127-4
- To prevent the relay contacts from welding in the event of short-circuit in the load circuit, fusing of the output relays must give consideration to the maximum permissible relay current
  - ⇒ Reference!  
See chapter 14.3 *Controller outputs* OutP.
- No other loads may be connected to the controller's main power supply terminals

#### Suppression of interference

- The electromagnetic compatibility and interference suppression levels conform to the standards and regulations listed under *Technical data*
  - ⇒ Reference!  
See chapter 14.5 *Electrical data*.
- Input, output and supply cables should be routed separately, not parallel to one another
- All input and output lines without connection to the power supply network must be shielded and twisted. They must not be run close to live components or live cables.


#### Incorrect use

- The controller is not suited for installation in areas with explosion hazard
- Incorrect settings on the controller (setpoint, data of parameter and configuration levels) can affect proper functioning of the process or lead to damage.  
Safety devices independent of the controller, such as overpressure relief valves or temperature limiters/monitors should therefore always be provided, and only be capable of adjustment by qualified personnel. Please observe the relevant safety regulations. Since self-setting cannot be expected to handle all possible control loops, the stability of the resulting actual value should be checked



## 4.2 Galvanic separation

The illustration shows the maximum test voltages between the electrical circuits.




7867d02e/0712

Figure 4: Test voltages



### 4.3 Assignment of terminals



Outputs	Display LED	Terminal no.	Connection diagram
Relay <i>Burner release</i> : Relay K1: 1P, 1N		1P pole  1N NO contact	<p style="font-size: x-small; text-align: right;">7866a01/0911</p>
3-position output:  Relay K3: Controlling element CLOSE  Relay K2: Controlling element OPEN	  	K3 NO contact  KQ common pole  K2 NO contact	<p style="font-size: x-small; text-align: right;">7866a02/0911</p>
Multifunctional relay K6: 6N, 6P	K6	6N NO contact  6P pole	<p style="font-size: x-small; text-align: right;">7867a12/0712</p>
Analog output A+, A- DC 0(4)...20 mA, DC 0...10 V		A+  A-	<p style="font-size: x-small; text-align: right;">7866a03/0911</p>



Analog input I nP1 (actual value)	Terminal no.	Connection diagram
Thermal element	12  14	
Resistance thermometer in 3-wire circuit	11  12  14	
Resistance thermometer in 2-wire circuit 0...135 Ω	11  14	
Current input DC 0...20 mA, 4...20 mA	12 +  14 -	
Voltage input DC 0...5 V, DC 1...5 V, DC 0...10 V	13 +  14 -	

Analog input I nP2 (external setpoint or setpoint shifting)	Terminal no.	Connection diagram
Resistance thermometer in 2-wire circuit 0...1000 Ω	21  23	
Current input DC 0...20 mA, 4...20 mA	21 +  23 -	
Voltage input DC 0...5 V, 1...5 V, 0...10 V	22 +  23 -	

Analog input I nP3 (outside temperature)	Terminal no.	Connection diagram
Resistance thermometer in 2-wire circuit	31  32	



Binary inputs b i nF	Terminal no.	Connection diagram
Binary input D1	D1	
Binary input D2	D2	
Common ground DG	DG	

Power supply	Terminal no.	Connection diagram
Power supply AC 110...240 V +10%/-15%, 48...63 Hz	L1 Live conductor  N Neutral conductor	
Power supply measuring transducer (short-circuit-proof)	G+  G-	

Interface	Terminal no.	Connection diagram
RS-485	R+ R-	RxD/TxD + RXD/TxD -
Only RWF55.6 Profibus DP	C1 C2 C3 C4	VP (+5 V) RxD/TxD-P (B) RxD/TxD-N (A) DGND



## 5 Operating modes

### 5.1 Low-fire operation

Low-fire operation means that only small amounts of heat are drawn from the boiler. Using relay K1 *Burner release*, the 2-position controller ensures control to the setpoint by switching the burner on and off like a thermostat.

#### Thermostat function

This mode of control is known as the **thermostat function**. An adjustable switching difference ensures that the burner's switching frequency can be selected, aimed at reducing wear.

#### Heating controller




Figure 6: Control sequence of heating controller

#### Modulating and 2-stage operation:

Actual value lies between switch-on threshold **HYS1** and switch-off threshold **HYS3**.

#### Cooling controller

If the controller is set to cooling mode, temperature limits **HYS4** and **HYS6** apply. In that case, relay K1 *Burner release* is used for controlling the cooling equipment.




Figure 7: Control sequence of cooling controller

#### Modulating and 2-stage operation:

Actual value lies between switch-on threshold **HYS4** and switch-off threshold **HYS6**.

## 5.2 High-fire operation

High-fire operation means that large amounts of heat are drawn from the boiler so that the burner runs continuously. If the heating load during low-fire operation rises to a level where the actual value begins to fall below switch-on threshold **HYS1**, the controller will not immediately switch to a higher burner output, but first makes a dynamic test of the control deviation and switches to the higher output only when an adjustable threshold (**q**) is exceeded (**A**).

⇒ Reference!  
See chapter 5.6 *Response threshold (q)*.

### Operating mode changeover

- In high-fire operation – depending on the application – the burner can be fired in **modulating** or **2-stage** operation, then burning larger amounts of fuel than in low-fire operation. **Binary input D2** can be used to switch between modulating and 2-stage operation
- Contacts **D2** and **DG** open: Modulating burner operation
- Contacts **D2** and **DG** closed: 2-stage burner operation

⇒ Reference!  
See chapter 8.8 *Binary functions b i nF*.

### 5.2.1 Modulating burner, 3-position output

#### Area (1)

In area (1), the thermostat function is active. The lowest burner stage is switched on below switch-on threshold **HYS1** and switched off above switch-off threshold **HYS3**.




Figure 8: Control sequence of modulating burner, 3-position output

#### Area (2)

Here, operating mode *Modulating burner* is shown. In high-fire operation, the 3-position controller acts on an actuator via relay K2 (OPEN) and relay K3 (CLOSE). When the actual value falls below the setpoint, the response threshold (**q**) at point (**A**) is reached and the controlling element opens (greater heat output). When the actual value lies within the dead band **db**, the controlling element remains inactive. When the actual value exceeds **db**, the controlling element closes (smaller heat output).

#### Area (3)

If the actual value exceeds the upper switch-off threshold **HYS3** in spite of the lowest heating stage, the controller switches the burner off (**B**). The controller only starts low-fire operation when the actual value falls below switch-on threshold **HYS1** again. If the response threshold (**q**) is exceeded, the controller switches to high-fire operation (**A**).

Reference!  
See chapter 5.6 *Response threshold (q)*.

## 5.2.2 Modulating burner, analog output

Area (1) Thermostat function active.

Area (2) The RWF55 as a modulating controller provides control to the adjusted setpoint. Angular positioning is ensured via the analog output in the form of a standard signal.




Figure 9: Control sequence of modulating burner, analog output

Area (3) The controller behaves as described in chapter 5.2.1 *Modulating burner, 3-position output*.

**Cooling controller** If the controller is set to cooling mode, the respective values **HYS4** and **HYS6** apply.

Starting from a high actual value, the controller now controls the connected cooling equipment in low-fire operation. In high-fire operation, the cooling output is controlled via relays K2 and K3 or the analog output. The response threshold (q) calculates automatically (now in the reverse sense) the point from which the cooling output is to be increased.

**Output** Angular positioning is ensured via the analog output in the form of a standard signal.



**Note!**  
The modulating controller must be configured.



**Reference!**  
See chapter 8.4 *Controller Cntr*



### 5.2.3 2-stage burner, 3-position output

In area (1), the thermostat function is active. In area (2), the RWF55 as a **2-position controller** acts on the second stage via relay K2 (OPEN) and relay K3 (CLOSE) by switching on at switch-on threshold **HYS1** and switching off at switch-off threshold **HYS2**.




Figure 10: Control sequence of 2-stage burner, 3-position output

In area (3), the actual value exceeds the upper switch-off threshold **HYS3** and the controller shuts down the burner (**B**). The controller only starts low-fire operation when the actual value falls again below switch-on threshold **HYS1**. If the response threshold ( $q$ ) is exceeded, the controller switches to high-fire operation (**A**).

⇒ Reference!  
See chapter 5.6 *Response threshold (q)*.



### 5.2.4 2-stage burner, analog output

In this case, a digital standard signal switches the second stage on via the analog output (terminals **A+** and **A-**) when reaching switch-on threshold **HYS1** and off at the lower switch-off threshold **HYS2**.




Figure 11: Control sequence of 2-stage burner, analog output

#### Cooling controller

If the controller is set to cooling mode, the respective values of HYS4, HYS5 and HYS6 apply.

Starting from a high actual value, the controller now controls the connected cooling equipment in low-fire operation. In high-fire operation, the second stage and thus the cooling output are controlled via relays K2 and K3 or the analog output. The response threshold (q) calculates automatically (now in the reverse sense) the point from which the cooling output is to be increased.



## 5.3 Burner shutdown

In the event of a sensor failure, the controller cannot monitor the actual value of the boiler temperature (analog input InP1). Burner shutdown will automatically be triggered to guard against overheating.

The same applies to acquiring the external setpoint using analog input InP2.

### Functions

- Burner off
- 3-position output for closing the controlling element
- Self-setting function is ended
- Manual control is ended



## 5.4 Predefined setpoint

The setpoints (SP1, SP2 or dSP) are predefined within the selected setpoint limits via the buttons or the ACS411 software.

It is possible to shift the setpoint using either an analog or a binary signal, to change it via an external contact, or to influence it using a weather-compensated method.

⇒ Reference!  
See chapter 8.8 *Binary functions b i nF*.

Setpoint changeover	Shifting	Binary input D1	Information	
SP1	Analog via InP2	Open	⇒	Reference! See chapter 5.4.1 <i>Setpoint changeover SP1/SP2, or shifting analog via InP2</i>
SP2	Analog via InP2	Closed		
SP1		Open	⇒	Reference! See chapter 5.4.2 <i>Setpoint changeover SP1 / external setpoint via InP2</i>
External setpoint via InP2		Closed		
	Setpoint SP1 analog via InP2, no binary shifting	Open	⇒	Reference! See chapter 5.4.3 <i>Setpoint shifting SP1 analog via InP2 / binary via dSP</i>
	Setpoint SP1 analog via InP2, binary shifting about setpoint dSP	Closed		
	External setpoint via InP2, no binary shifting	Open	⇒	Reference! See chapter 5.4.4 <i>External setpoint, setpoint shifting binary via dSP</i>
	External setpoint via InP2, binary shifting about setpoint dSP	Closed		

### 5.4.1 Setpoint changeover SP1 / SP2 or setpoint shift analog via InP2

⇒ See chapter 8.3 Analog input InP3

InP3 (outside temperature)  
FnC3 = 1, 2

⇒ See chapter 5.5 Weather compensated setpoint shifting

Heating curve  
Factory setting: At 1 = -10, Ht1 = 60, At2 = 20, Ht2 = 50

⇒ See chapter 7 Parameterization PArA

Function InP3:

⇒ See chapter 8.3 Analog input InP3

FnC3 = 0 no function

SP1 via keyboard entry

0

FnC3 = 1 weather-compensated setpoint

SP1 via outside sensor

1

Function of binary input D1:

b in I = 2

Setpoint shifting binary

2

b in I = 1

Setpoint changeover

1

b in I = 0 / 3

Without function, alarm input

0

Setpoint changeover:

SP2 via keyboard entry

D1 closed


D1 open

7867a19e/0912

Function InP2 : FnC2 = 2

Setpoint shifting analog via InP2

+



Binary input circuit D1:

⇒ See chapter 4.3 Assignment of terminals

Active setpoint

Figure 12: Setpoint changeover or setpoint shift

### 5.4.2 Setpoint changeover SP1/external setpoint via InP2






Figure 13: Setpoint changeover SP1 / external setpoint

### 5.4.3 Setpoint shifting SP1 analog via InP2 /binary via dSP






⇒ See chapter 8.3 Analog input InP3



⇒ See chapter 5.5 Weather-compensated setpoint shifting



⇒ See chapter 7 Parameterization PArA



7867a21e/0912

Active setpoint


Beschaltung binary input D1:

⇒ See chapter 4.3 Assignment of terminals

Figure 14: Setpoint shifting analog / binary

### 5.4.4 External setpoint, setpoint shifting binary via dSP

⇒ See chapter  
8.2 Analog input InP2



**Binary input circuit D1:**  
⇒ See chapter 4.3 Assignment of terminals

Figure 15: External setpoint, setpoint shifting binary via dSP



## 5.5 Weather-compensated setpoint shifting

The RWF55 can be configured so that weather-compensated setpoint shifting is activated when an LG-Ni1000 outside sensor or a Pt1000 is connected.

⇒ **Reference!**  
See chapter 8.3 *Analog input InP3*

To take into account the time response of a building, weather-compensated setpoint shifting uses the attenuated outside temperature rather than the current outside temperature.

This attenuated outside temperature is determined on the basis of the current outside temperature and a filter constant. With the RWF55, this filter value (parameter dF3) can be adjusted. In the event of a power failure, this filter is reset. The minimum and maximum setpoints can be set using the lower setpoint limit SPL and the upper setpoint limit SPH.

The system also prevents the lower working range limit oLLo and upper working range limit oLHi from exceeding/dropping below the system temperature limits.

☞ **Note!**  
Each RWF55 must have its own separate outside sensor (no parallel connection). This function has been optimized for heating systems with DHW.

### Heating curve

The heating curve describes the relationship between the boiler temperature setpoint and the outside temperature. It is defined by 2 curve points. For 2 outside temperatures, the user defines the boiler temperature setpoint that is required in each case. The heating curve for the weather-compensated setpoint is calculated on this basis. The effective boiler temperature setpoint is limited by the upper setpoint limit SPH and the lower setpoint limit SPL.




Figure 16: Heating curve slope

The two curve points are set at the parameter level.

⇒ **Reference!**  
See chapter 7 *Parameterization PARa*

## 5.6 Response threshold (q)

The response threshold (q) defines for what period of time and how much the actual value is allowed to drop before the system switches to high-fire operation.

An internal mathematical calculation using an integration function determines the sum of all areas  $q_{eff} = q_1 + q_2 + q_3$  as shown in the graph. This takes place only when the control deviation  $(x-w)$  falls below the value of switch-on threshold  $HYS1$ . If the actual value increases, integration is stopped.

If  $q_{eff}$  exceeds the preset response threshold (q) (can be adjusted at the parameter level), this causes the second burner stage to switch on or – in the case of the 3-position controller/modulating controller – the controlling element to open.

If the current boiler temperature reaches the required setpoint,  $q_{eff}$  is reset to 0.




Figure 17: Control sequence response threshold (q)

In contrast to time-dependent switching on, load-dependent switching on offers the advantage of capturing the dynamics of the actual value.

Also, monitoring the progression of the actual value during the change from low-fire to high-fire ensures low switching frequencies to reduce wear and to extend running times.

### Cooling controller

The response threshold (q) also works (in the reverse sense) in the case of cooling mode.

## 5.7 Cold start of plant

### Interlocking



**Note!**

Functions *Cold start of plant* and *Thermal shock protection (TSS)* are interlocked. Only one function can be activated, but never both at the same time.

### Heating controller

When a heating system is switched off for a longer period of time, the actual value will drop of course.

To achieve a faster control response, the controller immediately starts in high-fire operation as soon as the control deviation ( $x-w$ ) drops below a certain limit value.

This limit is calculated as follows:

$$\text{Limit value} = 2 \times (\text{HYS1} - \text{HYS3})$$

In that case, the response threshold ( $q$ ) is inactive, independent of operating mode and controlled variable (temperature or pressure).

### Example

Operating mode: Modulating, 3-position output

HYS1 = -5 K

HYS3 = +5 K

$w = 60 \text{ }^\circ\text{C}$

$$\text{Limit value} = 2 \times (-5 - 5) = 2 \times (-10) = -20 \text{ K}$$

At an actual value below  $40 \text{ }^\circ\text{C}$ , heating is immediately started in high-fire mode in place of low-fire mode.




Figure 18: Control sequence *Cold start of plant*

7866d10(0911)



### Cooling controller

Cold start of plant also works when the RWF55 is used as a cooling controller.

In that case, the limit value is calculated as follows:

$$\text{Limit value} = 2 \times (\text{HYS4} - \text{HYS6})$$

### Example

Operating mode: Modulating 3-position output

$$\text{HYS4} = 5 \text{ K}$$

$$\text{HYS6} = -5 \text{ K}$$

$$w = -30 \text{ }^\circ\text{C}$$

$$\text{Limit value} = 2 \times (5 + 5) = 2 \times (10) = +20 \text{ K}$$

When the actual value lies above  $-10 \text{ }^\circ\text{C}$ , cooling is immediately started in high-fire mode in place of low-fire mode.

## 5.8 Thermal shock protection (TSS)

### Interlocking



**Note!**

Functions *Cold start of plant* and *Thermal shock protection (TSS)* are interlocked. Only one function can be activated, but never both at the same time.

The controller comes with thermal shock protection (TSS) deactivated; it can be activated at the configuration level.



**Reference!**

See chapter 8.5 *Thermal shock protection (TSS) rAFC*.

### Function

The function is automatically activated when the actual value drops below the adjustable limit value rAL (exceeds the adjustable limit value with the cooling controller). In that case, the setpoint is approached via a ramp function.

Gradient and slope of the ramp rASL are adjustable. The setpoint ramp has a symmetrical tolerance band toLP. If, during the startup phase, the actual value leaves the tolerance band, the setpoint ramp is stopped until the actual value returns to a level within the tolerance band. The startup phase is ended when the setpoint of the ramp function reaches the final setpoint SP1.



**Note!**

When thermal shock protection (TSS) is active, the controller operates in low-fire operation. The response threshold (q) is active.






Figure 19: Thermal shock protection (TSS)

**Key**

-  Setpoint (w)
-  Actual value (x)

## 6 Operation

### 6.1 Meaning of display and buttons




Figure 20: Meaning of display and buttons

#### Initialization

The two 7-segment displays (red and green) show hyphens and all LEDs light up for about 5 seconds.

#### Basic display

The upper display (red) shows the actual value.  
The lower display (green) shows the setpoint.

⇒ Reference!  
See chapter 8.9 *Display d i SP.*

#### Parameter display

When entering parameters, the parameter symbol (green) and the set value (red) appear.

#### Self-setting function

The actual value is shown on the actual value display (red) and **tUnE** flashes on the setpoint display (green).

⇒ Reference!  
See chapter 9.1 *Self-setting function in the high-fire operation.*



**Flashing actual value display**

The actual value display (red) shows **9999** flashing → Alarm message.



Reference!

See chapter 13 *What to do if ...*

**Manual control**

The setpoint display (green) shows **HAnd** flashing.



Reference!

See chapter 6.4 *Manual control of a modulating burner.*



## 6.2 Basic display

When switching power on, the displays show hyphens for about 5 seconds.




Figure 21: Display start

The state that follows is called *normal display*.

Default display is the actual value and the current setpoint.

Other values can be displayed via configuration level or via PC software ACS411.

⇒ Reference!  
See chapter 8.9 *Display d i SP*.

Manual control, self-setting, the user level, parameter level and configuration levels can be activated from here.




Figure 22: Basic display





## 6.3 User level

This level is started from the basic display.

Setpoints SP1, SP2 or dSP can be altered.

The values of the analog inputs InP1, InP2, InP3 and SPE (external setpoint) and InP3 (actual angular positioning between 0...100%) can be displayed.

### Changing the setpoints

Changing SP1, SP2 or dSP.

- \* From the basic display, press so that **OPr** appears

SP1

- \* Press so that **SP1** appears
- \* Press and **SP1** flashes
- \* Press or to adjust the required setpoint and press to confirm

SP2

SP2 only appears if **setpoint changeover** is set (binary input b i n1 = 1).

- \* From the basic display, press so that **OPr** appears
- \* Press so that **SP1** appears
- \* Press to change over to SP2
- \* Press and **SP2** flashes
- \* Press or to adjust the required setpoint and press to confirm

dSP

dSP only appears if **setpoint shifting** is set (binary input b i n1 = 2).

- \* From the basic display, press so that **OPr** appears
- \* Press so that **SP1** appears
- \* Press to change over to dSP
- \* Press and **dSP** flashes
- \* Press or to adjust the required setpoint and press to confirm

Timeout after about 180 seconds.

Timeout



#### Note!

If the setpoint is not stored, the basic display changes after the timeout tout and the former setpoint is maintained.

The value changes only within the permitted range.



## 6.4 Manual control, modulating burner





**Note!**


Manual control can only be activated if the thermostat function **energized** relay K1. If the thermostat function **deenergized** relay K1 during manual control, manual control is ended.


- \* Press  for 5 seconds

**HAnd** appears on the lower display, alternating with the value for manual control (with continuous controller).

### 3-position controller




- \* Open and close fuel-air ratio control by pressing  and 

Relay K2 opens the controlling element as long as  is kept depressed.


Relay K3 closes the controlling element as long as  is kept depressed.

The 2 yellow arrows indicate when relay K2 opens or relay K3 closes the controlling element.

### Modulating controller

- \* Change angular positioning by pressing  or 
- \* Adopt flashing new angular positioning by pressing 

Per default, the analog output delivers the current angular positioning.

- \* Return to automatic operation by keeping  depressed for 5 seconds



**Note!**

When activating manual control, angular positioning is set to 0 until another entry is made.



## 6.5 Manual control, 2-stage burner



**Note!**

Manual control can only be activated if the thermostat function **active** relay K1. If the thermostat function **inactive** relay K1 during manual control, manual control is ended.

- \* Press  for 5 seconds
- \* Press  briefly

Relay K2 / K3	Analog output A- / A+
Relay K2 is active Relay K3 is inactive	The analog output delivers the highest value (depending on setting DC 10 V or 20 mA)
Controlling element opens	

- \* Or press  briefly

Relay K2 / K3	Analog output A- / A+
Relay K2 is inactive Relay K3 is active	The analog output delivers the lowest value (depending on setting DC 0 V, 4 mA, or 0 mA)
Controlling element closes	

- \* Return to automatic operation by pressing  for 5 seconds





## 6.6 Starting the self-setting function

### Start

- \* Press  +  for 5 seconds

### Cancel

- \* Cancel with  + 




Figure 23: Display of self-setting function

When **t UnE** stops flashing, the self-setting function has been ended.

The parameters calculated by the controller are automatically adopted!



#### Note!

It is not possible to start **t UnE** in manual control or low-fire operation.



## 6.7 Display of software version

- \* Press +



Figure 24: Display of software version

### Segment test

- \* Press + again.




Figure 25: Display segment test

All display segments and LEDs light up; the actual value display (red) flashes for about 10 seconds.



## 7 Parameterization PArA

Here, set the parameters associated directly with the controller's adaptation to the controlled system after the plant has been put into operation.



### Note!

The display of the individual parameters depends on the type of controller.




Figure 26: Parameterization

Access to this level can be locked.



### Reference!


See chapter 8.9 *Display d i SP*.

- \* From the basic display, press so that **OPr** appears
- \* Press so that **PArA** appears
- \* Press so that the first parameter of the parameter level is displayed




Display of controller parameters

The parameters are shown on the lower setpoint display (green) and their values on the upper/actual value display (red).



Parameter	Display	Value range	Factory setting	Remarks
Proportional band <sup>1</sup>	<b>Pb1</b>	1...9999 digit	10	Influences the controller's P-action
Derivative time	<b>dt</b>	0...9999 s	80	Influences the controller's D-action With dt = 0, the controller has no D-action
Integral action time	<b>r t</b>	0...9999 s	350	Influences the controller's I-action With rt = 0, the controller has no I-action
Dead band (neutral zone) <sup>1</sup>	<b>db</b>	0.0...999.9 digit	1	For 3-position output 
Controlling element running time	<b>tt</b>	10...3000 s	15	Running time of the positioning valve for use with modulating controllers
Switch-on threshold Heating controller <sup>1</sup>	<b>HYS1</b>	-1999...0.0 digit	-5	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Switch-off threshold stage II Heating controller <sup>1</sup>	<b>HYS2</b>	0.0...HYS3 digit	3	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Switch-off threshold Heating controller <sup>1</sup>	<b>HYS3</b>	0.0...9999 digit	5	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Switch-on threshold Cooling controller <sup>1</sup>	<b>HYS4</b>	0.0...9999 digit	5	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Switch-off threshold stage II Cooling controller <sup>1</sup>	<b>HYS5</b>	HYS6...0.0 digit	-3	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Switch-off threshold Cooling controller <sup>1</sup>	<b>HYS6</b>	-1999...0.0 digit	-5	⇒ Reference! See chapter 5.2 <i>High-fire operation</i>
Response threshold	<b>q</b>	0.0...999.9	0	⇒ Reference! See chapter 5.6 <i>Response threshold (q)</i>



Parameter	Display	Value range	Factory setting	Remarks
Outside temperature Curve point 1 <sup>1</sup>	At 1	-40...120	-10	⇒ Reference! See chapter 5.5 <i>Weather-compensated setpoint shifting</i>
Boiler temperature Curve point 1 <sup>1</sup>	Ht 1	SPL...SPH	60	⇒ Reference! See chapter 5.5 <i>Weather-compensated setpoint shifting</i>
Outside temperature Curve point 2 <sup>1</sup>	At 2	-40...120	20	⇒ Reference! See chapter 5.5 <i>Weather-compensated setpoint shifting</i>
Boiler temperature Curve point 2 <sup>1</sup>	Ht 2	SPL...SPH	50	⇒ Reference! See chapter 5.5 <i>Weather-compensated setpoint shifting</i>

<sup>1</sup> Setting of decimal place has an impact on this parameter



**Note!**

When using the RWF55... as a modulating controller only, or as a modulating controller without the burner release function (1P, 1N), parameter HYS1 must be set to 0 and parameters HYS2 and HYS3 must be set to their **maximum** values.

Otherwise, for example, when using default parameter HYS1 (factory setting -5), the 3-position controller is only released when the control deviation reaches -5 K.





## 8 Configuration ConF

Here, the settings (e.g. acquisition of measured value or type of controller) required directly for commissioning a certain plant are made and, for this reason, there is no need to change them frequently.




Figure 27: Configure

Access to this level can be locked.

⇒ Reference!  
See chapter 8.9 *Display d i SP*.


☞ Note!  
The following tables show the default settings in columns *Value/selection* and *Description* in **bold printing**.



## 8.1 Analog input InP1

This input is used to acquire the actual value.

ConF → InP → InP1 →

Parameter	Value/ selection	Description									
<b>Sensor type</b> SEn1 Sensor type	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19	<b>Resistance thermometer Pt100, 3-wire</b> Resistance thermometer Pt100, 2-wire Resistance thermometer Pt1000, 3-wire Resistance thermometer Pt1000, 2-wire Resistance thermometer LG-Ni1000, 3-wire Resistance thermometer LG-Ni1000, 2-wire 0...135 Ohm Cu-CuNi T Fe-CuNi J NiCr-Ni K NiCrSi-NiSi N Pt10Rh-Pt S Pt13Rh-Pt R Pt30Rh-Pt6Rh B 0...20 mA 4...20 mA DC 0...10 V DC 0...5 V DC 1...5 V									
<b>Correction of measured value</b> OFF1 Offset	-1999... <b>0...</b> +9999	Using the measured value correction (offset), a measured value can be corrected to a certain degree, either up or down  <b>Example:</b>  <table border="1"> <thead> <tr> <th>Measured value</th> <th>Offset</th> <th>Displayed values</th> </tr> </thead> <tbody> <tr> <td>294.7</td> <td>+0.3</td> <td>295.0</td> </tr> <tr> <td>295.3</td> <td>-0.3</td> <td>295.0</td> </tr> </tbody> </table>	Measured value	Offset	Displayed values	294.7	+0.3	295.0	295.3	-0.3	295.0
Measured value	Offset	Displayed values									
294.7	+0.3	295.0									
295.3	-0.3	295.0									
 <b>Caution!</b> <b>Measured value correction:</b>	To make the calculation, the controller uses the corrected value (displayed value). This value does not represent the value acquired at the point of measurement. If the measured value correction function is used incorrectly (e.g., overcompensation of measured values → measurement error only present temporarily), this may lead to undesirable plant states.										
<b>Start of display</b> SCL1 Scale low level	-1999... <b>0...</b> +9999	In the case of a measuring transducer with standard signal, the physical signal is assigned a display value here  Example: 0...20 mA = 0...1500 °C									
<b>End of display</b> SCH1 Scale high level	-1999... <b>100...</b> +9999	The range of the physical signal can be crossed by 20%, either up or down, without getting a signal informing about the crossing									




Parameter	Value/ selection	Description
<b>Filter time constant</b> dF1 Digital filter	0.0... <b>0.6...</b> 100.0...	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off)  If the input signal changes abruptly, about 26% of the change are captured after a time corresponding to the filter time constant <b>dF</b> (2 x dF: approx. 59%; 5 x dF: approx. 96%)  When the filter time constant is great: - Great attenuation of interference signals - Slow response of actual value display to changes of the actual value - Low limit frequency (low-pass filter)
<b>Temperature unit</b> Un it Temperature unit	<b>1</b> 2	<b>Degrees Celsius</b> <b>Degrees Fahrenheit</b>  Unit of temperatures



## 8.2 Analoginput InP2

This input can be used to specify an external setpoint or carry out setpoint shifting.

ConF → InP → InP2 →


Parameter	Value/ selection	Description									
<b>Function</b> FnC2	<b>0</b> 1 2 3	<b>No function</b> External setpoint (display SPE) Setpoint shifting (display dSP) Angular positioning feedback									
<b>Sensor type</b> SEn2 Sensor type	<b>1</b> 2 3 4 5 6	<b>0...20 mA</b> 4...20 mA 0...10 V 0...5 V 1...5 V Resistance teletransmitter									
<b>Correction of measured value</b> OFF2 Offset	-1999... <b>0...</b> +9999	Using the measured value correction function (offset), a measured value can be corrected by a certain amount, either up or down.  <b>Example:</b>  <table border="1"> <thead> <tr> <th>Measurement value</th> <th>Offset</th> <th>Display value</th> </tr> </thead> <tbody> <tr> <td>294.7</td> <td>+0.3</td> <td>295.0</td> </tr> <tr> <td>295.3</td> <td>-0.3</td> <td>295.0</td> </tr> </tbody> </table>	Measurement value	Offset	Display value	294.7	+0.3	295.0	295.3	-0.3	295.0
Measurement value	Offset	Display value									
294.7	+0.3	295.0									
295.3	-0.3	295.0									
 <b>Caution!</b> <b>Measured value correction:</b> To make the calculation, the controller uses the corrected value (displayed value). This value does not represent the value acquired at the point of measurement. If the measured value correction function is used incorrectly (e.g., overcompensation of measured values → measurement error only present temporarily), this may lead to undesirable plant states.											
<b>Start of display</b> SCL2 Scale low level	-1999... <b>0...</b> +9999	In the case of a measuring transducer with standard signal, the physical signal is assigned a display value here.  Example: 0...20 mA = 0...1500 °C									
<b>End of display</b> SCH2 Scale high level	-1999... <b>100...</b> +9999	The physical signal range can be undershot/exceeded by 20% without a measuring range overshoot/undershoot signal being issued.									
<b>Filter time constant</b> dF2 Digital filter	0.0... <b>2...</b> 100.0...	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off).  If the input signal changes abruptly, about 26% of the change is captured after a time corresponding to the filter time constant <b>dF</b> (2 x dF: approx. 59%; 5 x dF: approx. 96%).  If the filter time constant is large: <ul style="list-style-type: none"> <li>- High attenuation of interference signals</li> <li>- Slow response of actual value display to changes in the actual value</li> <li>- Low limit frequency (low-pass filter)</li> </ul>									



## 8.3 Analoginput InP3

This input is used to acquire the outside temperature.

ConF → InP → InP3 →




Parameter	Value/ selection	Description									
<b>Sensor type</b> SEn3 Sensor type	<b>0</b> 1 2	<b>Switched-off</b> Resistance thermometer Pt1000 in 2-wire circuit Resistance thermometer LG-Ni1000 in 2-wire circuit									
<b>Function</b> FnC3	<b>0</b> 1	<b>No function</b> Weather-compensated setpoint									
<b>Correction of measured value</b> OFF3 Offset	-1999... <b>0...</b> +9999	Using the measured value correction function (offset), a measured value can be corrected by a certain amount, either up or down.  <b>Example:</b>  <table border="1"> <thead> <tr> <th>Measurement value</th> <th>Offset</th> <th>Display value</th> </tr> </thead> <tbody> <tr> <td>294.7</td> <td>+0.3</td> <td>295.0</td> </tr> <tr> <td>295.3</td> <td>-0.3</td> <td>295.0</td> </tr> </tbody> </table>	Measurement value	Offset	Display value	294.7	+0.3	295.0	295.3	-0.3	295.0
Measurement value	Offset	Display value									
294.7	+0.3	295.0									
295.3	-0.3	295.0									
	<b>Caution!</b> <b>Measured value correction:</b>	To make the calculation, the controller uses the corrected value (displayed value). This value does not represent the value acquired at the point of measurement. If the measured value correction function is used incorrectly (e.g., overcompensation of measured values → measurement error only present temporarily), this may lead to undesirable plant states.									
<b>Filter time constant</b> dF3 Digital filter	0.0... <b>1278...</b> 1500.0...	Is used to adapt the digital 2nd order input filter (time in s; 0 s = filter off).  If the input signal changes abruptly, about 26% of the change is captured after a time corresponding to the filter time constant <b>dF</b> (2 x dF: approx. 59%; 5 x dF: approx. 96%).  If the filter time constant is large: - High attenuation of interference signals - Slow response of actual value display to changes in the actual value - Low limit frequency (low-pass filter)									



## 8.4 Controller Cntr

Here, the type of controller, operating action, setpoint limits and presettings for self-optimization are selected.

ConF → Cntr →




Parameter	Value/ selection	Description
<b>Controller type</b> Ct YP Controller type	1 2	<b>3-position controller</b> Modulating controller
<b>Operating action</b> CACt Control direction	0 1	Cooling controller <b>Heating controller</b>  <p>(0) = cooling controller: The controller's angular positioning (Y) is &gt;0 when the actual value (x) lies above the setpoint (w)</p> <p>(1) = heating controller: The controller's angular positioning (Y) is &gt;0 when the actual value (x) lies below the setpoint (w)</p>
<b>Setpoint limitation start</b> SPL Setpoint limitation low	-1999... 0... +9999	Setpoint limitation prevents values from being entered outside the defined range.
<b>Setpoint limitation end</b> SPH Setpoint limitation high	-1999... +100... +9999	The setpoint limits are not active in the case of predefining setpoints via the interface. In the case of an external setpoint with correction, the correction value is limited to SPL / SPH.
<b>Self-optimization</b>	0 1	<b>Free</b> Locked  Self-optimization can only be disabled or enabled via the ACS411 setup program  If disabled via ACS411 PC software, self-optimization cannot be started via the controller's buttons  Setting in the ACS411 setup program → Controller → Self-optimization  Self-optimization is also disabled when the parameter level is locked
<b>Lower working range limit</b> oLLo Lower operation range limit	-1999... +9999	 <b>Note!</b> If the setpoint with the respective hysteresis exceeds the upper working range limit, the switch-on threshold is substituted by the working range limit.
Upper working range limit oLHi Upper working range limit	-1999... +9999	 <b>Note!</b> If the setpoint with the respective hysteresis drops below the lower working range limit, the switch-off threshold is substituted by the working range limit.



## 8.5 Thermal shock protection (TSS) rAFC

The RWF55... can be operated as a fixed value controller with or without ramp function.

ConF → rAFC →

Parameter	Value/ selection	Description
<b>Function</b> FnCt Function	<b>0</b> 1 2	<b>Switched off</b> Gradient Kelvin/minute Gradient Kelvin/hour  <p style="background-color: yellow;">With <b>FnCt</b> = 1 or 2, <i>Thermal shock protection (TSS)</i> is <b>Note!</b></p> <p>automatically activated as soon as the actual value drops below the adjustable absolute limit value <b>rAL</b> (heating controller) or exceeds it (cooling controller).</p>
<b>Ramp slope</b> rASL Ramp slope	<b>0.0...</b> 999.9	Slope of <b>ramp</b> slope (only with functions 1 and 2)
<b>Tolerance band ramp</b> toLP Tolerance band ramp	<b>2 x  HYS1 </b> = <b>10...9999</b>	Width of tolerance band (in K) about the setpoint (only with function 1 and 2)  Heating controller: Smallest possible factory setting: <b>2 x  HYS1  = 10 K</b> To monitor the actual value in connection with thermal shock protection (TSS), a tolerance band can be laid about the setpoint curve. If the limit values are crossed, the ramp is stopped.   <span style="background-color: yellow;">Reference! See chapter 5.8 <i>Thermal shock protection (TSS)</i>.</span>  Cooling controller: Smallest possible factory setting: <b>2 x  HYS4  = 10 K</b>
	<p style="background-color: yellow;"><b>Note!</b> In the event of a faulty sensor or manual control, the ramp function is stopped. The outputs behave the same way they do when the measuring range is crossed (configurable). Functions <i>Cold start of plant</i> and <i>Thermal shock protection (TSS)</i> are interlocked. Only one function can be activated, but never both at the same time.</p>	
<b>Limit value</b> rAL Ramp limit	<b>0...250</b>	<b>Heating controller:</b> If the actual value lies below this limit value, the setpoint is approached in the form of a ramp until final setpoint SP1 is reached.  <b>Cooling controller:</b> If the actual value lies above this limit value, the setpoint is approached in the form of a ramp until final setpoint SP1 is reached.

## 8.6 Alarm function AF


ConF → AF →

The alarm function can be used to monitor the analog inputs. If the limit value is exceeded, multifunctional relay K6 is activated (depending on the switching characteristic). The alarm function can have different switching functions (**Ik1** to **Ik8**) and can be set to a deviation from the active setpoint or to a fixed limit value.


Limit value AL relative to setpoint (w)

In the case of alarm functions **Ik1** to **Ik6**, the actual value InP1 is monitored in relation to a limit value AL that has to be set (with the absolute value dependent on the setpoint (w)).


**Ik1**




**Ik2**




**Ik3**



**Ik4**



**Ik5**



**Ik6**





Figure 28: Alarm function Ik1...Ik6

Fixed limit value AL

In the case of alarm functions **Ik7** and **Ik8**, all analog inputs InP1... InP3 can be monitored in relation to a fixed limit value AL that has to be set.

**Ik7**



**Ik8**




Figure 29: Alarm function Ik7 and Ik8





Parameter	Value/ selection	Description
<b>Function</b> FnCt Function	<b>0</b> 1 2 3 4 5 6 7 8 9 10 11 12	<b>Without function</b> <b>Ik1</b> monitored input InP1 <b>Ik2</b> monitored input InP1 <b>Ik3</b> monitored input InP1 <b>Ik4</b> monitored input InP1 <b>Ik5</b> monitored input InP1 <b>Ik6</b> monitored input InP1 <b>Ik7</b> monitored input InP1 <b>Ik8</b> monitored input InP1 <b>Ik7</b> monitored input InP2 <b>Ik8</b> monitored input InP2 <b>Ik7</b> monitored input InP3 <b>Ik8</b> monitored input InP3
<b>Limit value</b> AL Alarm value	-1999... <b>0...</b> +9999	Limit value or deviation from setpoint to be monitored (see alarm functions <b>Ik1</b> to <b>Ik8</b> : limit value AL).  Limit value range for <b>Ik1</b> and <b>Ik2</b> : 0...9999
<b>Switching difference</b> HYSt Hysteresis	0... <b>1...</b> 9999	Switching difference in relation to limit value (see alarm functions <b>Ik1</b> to <b>Ik8</b> : hysteresis HYSt).
<b>Response by Out of Range</b> ACrA Response by out of range	<b>0</b> 1	Switching state in the case of measuring range overshoot or undershoot (Out of Range).  <b>Switched-off</b> ON



## 8.7 Control outputs OutP

For fuel-air ratio control purposes, the RWF55 has the binary outputs (K2, K3) and the analog output (A+, A-).

The burner is released via relay K1.

The switching states of relay K1 *Burner release* (LED green), relay K2 *Controlling element OPEN*, and relay K3 *Controlling element CLOSE* (yellow LED arrows) are indicated on the controller front.

### Binary outputs


The binary outputs of the RWF55 offer no setting choices.

### Analog output

The RWF55 has an analog output.

The analog output offers the following setting choices:

ConF → Out P →

Parameter	Value/ selection	Description
<b>Function</b> FnCt Function	0 1 2 3 <b>4</b>	No function Input InP1 is delivered Input InP2 is delivered Input InP3 is delivered <b>Controller's angular positioning is delivered (modulating controller)</b>
<b>Signal type</b> SiGn Type of signal	<b>0</b> 1 2	<b>0...20 mA</b> 4...20 mA DC 0...10 V  Physical output signal
<b>Value when out of range</b> rOut Value when out of range	<b>0...101</b>	Signal (in percent) when measuring range is crossed  101 = last output signal
<b>Zero point</b> OPnt Zero point	-1999... <b>0...</b> +9999	A value range (in percent) of the output variable is assigned to a physical output signal.
<b>End value</b> End End value	-1999... <b>100...</b> +9999	 <b>Note!</b> To avoid distorting the controller results, the <i>end value</i> and <i>zero point</i> values – in combination with Function 4: <i>Controller's angular positioning is delivered</i> – should not be changed.



## 8.8 Binary input binF

This setting decides on the use of the binary inputs.

⇒ Reference!  
See chapter 5.4 *Preselected setpoint*

ConF → binF →

Parameter	Value/ selection	Description
<b>Binary inputs</b>	<b>0</b>	<b>No function</b>
bin1 Binary input 1	1	Setpoint changeover
	2	Setpoint shift
	3	Alarm input
bin2 Binary input 2	<b>4</b>	<b>Changeover of operating mode</b>
		Burner modulating: Contacts D2 and DG open
		Burner 2-stage: Contacts D2 and DG closed



## 8.9 Display diSP

By configuring the position of the decimal point and automatic changeover (timer), both LED indications can be adapted to the respective requirements. Timeout tout for operation and the locking of levels can be configured as well.

ConF → d ISP →

Parameter	Value/ selection	Description
<b>Upper display</b> diSU Upper display	0 1 2 3 4 6 7	Display value for upper display  Switched off <b>Analog input</b> InP1 Analog input I nP2 Analog input I nP3 Controller's angular positioning Setpoint End value with thermal shock protection
<b>Lower display</b> diSL Lower display	0 1 2 3 4 6 7	Display value for lower display  Switched off Analog input I nP1 Analog input I nP2 Analog input I nP3 Controller's angular positioning <b>Setpoint</b> End value with thermal shock protection
<b>Timeout</b> tout	0... <b>180...</b> 255	Time (s) on completion of which the controller returns automatically to the basic display, if no button is pressed
<b>Decimal point</b> dECP Decimal point	<b>0</b> 1 2	<b>No decimal place</b> One decimal place Two decimal places  If the value to be displayed cannot be shown with the programmed decimal point, the number of decimal places is automatically reduced. If the measured value drops again, the number of decimal places is increased until the programmed value is reached
<b>Locking of levels</b> CodE	<b>0</b> 1 2 3	<b>No locking</b> Locking of configuration level Locking of parameter level Locking of keyboard



## 8.10 Interface Int F

The controller can be integrated into a data network using an optional RS-485 interface or an optional Profibus DP interface.

ConF → Int F →

Parameter	Value/ selection	Description
<b>Baud rate</b> bdr t Baud rate	<b>0</b> 1 2 3	<b>4800 Baud</b> 9600 Baud 19200 Baud 38400 Baud
<b>Device address</b> <b>Modbus</b> Adr Device address	0... <b>1...</b> 254	Address in the data network
<b>Device address</b> <b>Profibus</b> dP Device address	0... <b>125</b>	Only RWF55.6
<b>Remote Detection</b> <b>Timer</b> dtt Remote detection timer	0... <b>30...</b> 7200 s	0 = Switched-off



**Note!**

If communication is taking place via the setup interface, the other interfaces are inactive.

## 9 Self-setting function

### 9.1 Self-setting function in high-fire operation



Note!

**t UnE** is only possible in high-fire operation, in *modulating burner* mode.

Self-setting function **t UnE** is a proper software function unit integrated in the controller. In *modulating* mode, **t UnE** tests in high-fire operation the response of the controlled system to angular positioning steps according to a special procedure. A complex control algorithm uses the response of the controlled system (actual value) to calculate and automatically store the control parameters for a PID or PI controller (set  $dt = 0!$ ). The **t UnE** procedure can be repeated any number of times.




Figure 30: Self-setting function in high-fire operation

## 2 procedures

The **tUnE** function uses 2 different methods that are automatically selected depending on the dynamic state of the actual value and the deviation from the setpoint at startup. **tUnE** can be started from within any dynamic actual value sequence.

If there is a **great difference between actual value and setpoint** when **tUnE** is activated, a switching line is established about which the controlled variable performs forced oscillations during the self-setting process. The switching line is set to such a level that the actual value should not exceed the setpoint.




Figure 31: Great difference between actual value and setpoint

With a **small deviation** between setpoint and actual value (after the controlled system has settled, for instance), forced oscillation about the setpoint is performed.




Figure 32: Small control deviation

The data of the controlled system recorded for the forced oscillations are used to calculate the controller parameters **rt**, **dt**, **Pb1** and a filter time constant **dF1** for actual value filtering that is optimized for this controlled system.

## Conditions

- High-fire operation in *modulating burner* mode
- The thermostat function (relay K1) must be constantly activated; otherwise **tUnE** will be canceled and no optimized controller parameters will be adopted
- The above mentioned actual value oscillations during the self-setting process must not exceed the upper threshold of the thermostat function (increase if necessary, and lower the setpoint)



### Note!

A successfully started *Self-setting* function is automatically aborted after 2 hours. This could occur in the case of a controlled system that responds slowly, for example, where, even after 2 hours, the described procedures cannot be successfully completed.



## 9.2 Checking the controller parameters

Optimum adjustment of the controller to the controlled system can be checked by recording a startup sequence with the control loop closed. The following diagrams indicate possible incorrect adjustments, and their correction.

Example

The response to a setpoint change is shown here for a 3rd order controlled system for a PID controller. The method used for adjusting the controller parameters can, however, also be applied to other controlled systems. A suitable value for  $dt$  is  $r t / 4$ .

**Pb too small**




Figure 33: Pb too small

**Pb too large**




Figure 34: Pb too large

**rt, dt too small**




Figure 35: rt, dt too small

**rt, dt too large**




Figure 36: r t , dt too large

**Optimum adjustment**




Figure 37: Optimum adjustment





## 10 PC software ACS411

PC software ACS411 is an operating module for use with the RWF55... universal controller and designed for the following basic tasks:

- Visualization of system state covering the following data:
  - Parameters
  - Process data
  - Configuration and parameterization of the controller (individual parameters)
  - Saving and restoration of parameter sets

A USB cable can be used to establish the connection between PC (USB plug type A, 4 pins) and RWF55 (USB plug type Mini B, 5 pins).



### Note!

The cable must be purchased on site.

### 10.1 Safety notes



#### Caution!

PC software ACS411 is a convenient tool for use by qualified personnel, designed to commission and optimize the universal controller. Since the required actions and settings are safety-related, the user has a special obligation to exercise due care. Although specific technical measures have been taken to prevent incorrect entry of data and wrong parameter values, the user must check the correct function of the plant in a conventional way both during and after commissioning and – if required – ensure manual shutdown.

### 10.2 Setting the correct system parameters



#### Caution!

It should be noted that the characteristics of the universal controller are determined primarily by the parameter settings made, rather than by the type of unit. It is especially the OEM which is responsible for making certain that the controller's parameter settings are in compliance with the standards covering the respective application or type of plant. Responsibility for the parameter settings is assumed by the person who, in accordance with the access rights, makes or has made changes at the respective setting level. The detailed descriptions and safety notes given in the User Manual on the system components must also be observed.

### 10.3 Changing the parameters or the plant's configuration



#### Caution!

After changing parameters, all parameters must be checked via the unit's display to ensure they are correctly set – without making use of the PC software ACS411.



## 10.4 Place of installation



### Caution!

PC software ACS411 is designed for use on site, that is, within viewing and hearing distance of the respective combustion plant. This means that remote control is not permitted.

## 10.5 License and liability regulations



### Note!

For ENDUSER LICENSE AGREEMENT for PC software ACS411, refer to program menu item *Info* → *Software documentation*.

**IMPORTANT – PLEASE READ CAREFULLY!**

## 10.6 Procurement of PC software ACS411

For ordering the ACS411 software and updates, please contact your supplier or heating engineer.

## 10.7 Languages

PC software ACS411 is available in English and German. To select the language you require, go to program menu item *File* → *Default settings* → *Program language* (ACS411 setup program must be restarted).

## 10.8 Operating systems : Operating

- Windows 2000 SP4
- Windows 7 - 32 bit
- Windows 7 - 64 bit
- Windows VISTA
- Windows XP

## 10.9 Prerequisites for hardware

- Free hard disk memory: 300 MB
- RAM: 512 MB



## 10.10 Installation



### Note!

First, install PC software ACS411; then, connect the controller. If not observed, an error message is delivered.

PC software ACS411 is supplied on a CD.

- \* Insert CD in the CD or DVD drive.  
Setup starts automatically.
- \* Follow the instructions appearing on the screen.
- \* Connect PC and controller via the USB cable.  
New hardware is identified and USB driver installed.  
This may take a few minutes.
- \* Follow further instructions given on the screen and wait until the installation is successfully completed.

## 10.11 Others

### 10.11.1 Use of USB port : Use of

#### Use

The USB port is intended for temporary use to make the parameter settings, the configuration and for work in connection with commissioning.  
When using the USB port, the controller can be securely operated, tested and set with no need for using the mains cable.

### 10.11.2 Powering the controller via the USB port : Powering the controller

via the port

**Using the HUB:** Using the

If the controller shall be powered via the USB port, a HUB with power supply is required, capable of delivering at least 500 mA at every outlet.

**Switching off:** Switching off

When supplying power via the USB port, relays and analog output are deenergized to reduce power consumption.



### Note!

Check to ensure that power supply to the measuring converter (G+ and G-) is not connected. This increases power usage via the USB port as well.

**Measuring accuracy:**

The measuring accuracy specified in chapter 12 *Technical data* does not apply when powering the controller via the USB port.



## 11 Modbus interface

The tables that follow in this chapter specify the addresses of the readable and writable words that the customer is able to access. The customer may read and/or write the values using SCADA programs, PLCs, or similar.

The entries under *Access* have the following meanings:

**R/O** Read Only, value can only be read  
**R/W** Read/Write, value can be read and written

The number of characters specified under *Data type* in the case of character strings includes the final **\0**.

Example:

**Char10** means that the text is up to **9** characters long. The final **\0** character is then added to this.

### 11.1 User level

Address	Access	Data type	Signal reference	Parameter
0x0000	R/O	Float	X1	Analog input I nP1
0x0002	R/O	Float	X2	Analog input I nP2
0x0004	R/O	Float	X3	Analog input I nP3
0x0006	R/O	Float	WR	Actual setpoint
0x0008	R/W	Float	SP1	Setpoint 1
0x000A	R/W	Float	SP2 (= dSP)	Setpoint 2
0x1035	R/O	Float	---	Analog input I nP3 (unfiltered)
0x1043	R/O	Float	---	Actual angular positioning
0x1058	R/O	Word	B1	Burner alarm



## 11.2 Parameter level

Address	Access	Data type	Signal reference	Parameter
0x3000	R/W	Float	Pb1	Proportional range 1
0x3004	R/W	Float	dt	Derivative action time
0x3006	R/W	Float	r t	Integral action time
0x300C	R/W	Float	db	Dead band
0x3012	R/W	Word	tt	Controlling element running time
0x3016	R/W	Float	HYS1	Switch-on threshold
0x3018	R/W	Float	HYS2	Switch-off threshold down
0x301A	R/W	Float	HYS3	Switch-off threshold up
0x301C	R/W	Float	HYS4	Switch-on threshold (cooling)
0x301E	R/W	Float	HYS5	Switch-off threshold down (cooling)
0x3020	R/W	Float	HYS6	Switch-off threshold up (cooling)
0x3022	R/W	Float	q	Reaction threshold
0x3080	R/W	Float	At 1	Outside temperature 1
0x3082	R/W	Float	Ht 1	Boiler temperature 1
0x3084	R/W	Float	At 2	Outside temperature 2
0x3086	R/W	Float	Ht 2	Boiler temperature 2



## 11.3 Configuration level

Address	Access	Data type	Signal reference	Parameter
0x3426	R/W	Float	SCL1	Start of display input 1
0x3428	R/W	Float	SCH1	End of display input 1
0x3432	R/W	Float	SCL2	Start value input 2
0x3434	R/W	Float	SCH2	End value input 2
0x3486	R/W	Float	SPL	Start of setpoint limitation
0x3488	R/W	Float	SPH	End of setpoint limitation
0x342A	R/W	Float	OFFS1	Offset input E1
0x3436	R/W	Float	OFFS2	Offset input E2
0x343A	R/W	Float	OFFS3	Offset input E3
0x1063	R/W	Word	FnCt	Ramp function
0x1065	R/W	Float	rASL	Ramp slope
0x1067	R/W	Float	toLP	Tolerance band ramp
0x1069	R/W	Float	rAL	Limit value
0x1075	R/W	Float	dtT	Remote Detection Timer
0x1077	R/W	Float	dF1	Filter constant input 1
0x1079	R/W	Float	dF2	Filter constant input 2
0x107B	R/W	Float	dF3	Filter constant input 3
0x107D	R/O	Float	oLLo	Lower working range limit
0x107F	R/O	Float	oLHi	Upper working range limit
0x106D	R/W	Word	FnCt	Alarm relay function
0x106F	R/W	Float	AL	Alarm relay limit value (limit value alarm)
0x1071	R/W	Float	HYSt	Alarm relay hysteresis

## 11.4 Remote operation

Address	Access	Data type	Signal reference	Parameter
0x0500	R/W	Word	REM	Activation remote operation *
0x0501	R/W	Word	rOFF	Controller OFF in remote setpoint **
0x0502	R/W	Float	rHYS1	Switch-on threshold remote
0x0504	R/W	Float	rHYS2	Switch-off threshold down remote
0x0506	R/W	Float	rHYS3	Switch-off threshold up remote
0x0508	R/W	Float	SPr	Setpoint remote
0x050A	R/W	Word	RK1	Burner release remote operation
0x050B	R/W	Word	RK2	Relay K2 remote operation
0x050C	R/W	Word	RK3	Relay K3 remote operation
0x050D	R/W	Word	RK6	Relay K6 remote operation
0x050E	R/W	Word	rSt EP	Step-by-step control remote operation
0x050F	R/W	Float	rY	Angular positioning output remote operation
0x0511	R/W	Float	rHYS4	Switch-on threshold remote (cooling)
0x0513	R/W	Float	rHYS5	Switch-off threshold down remote (cooling)
0x0515	R/W	Float	rHYS6	Switch-off threshold up remote (cooling)

Legend

\* = Local

\*\* = Controller OFF



## 11.5 Device data

Address	Access	Data type	Signal reference	Parameter
0x8000	R/O	Char12	---	Software version
0x8006	R/O	Char14	---	VdN number

## 11.6 Device state

Address	Access	Data type	Signal reference	Parameter
0x0200	R/O	Word	---	Outputs and states
			Bit 0	Output 1
			Bit 1	Output 3
			Bit 2	Output 2
			Bit 3	Output 4
			Bit 8	Hysteresis limitation
			Bit 9	Control system
			Bit 10	Self-optimization
			Bit 11	Second setpoint
			Bit 12	Measuring range overshoot InP1
			Bit 13	Measuring range overshoot InP2
			Bit 14	Measuring range overshoot InP3
			Bit 15	Calibration mode
0x0201	R/O	Word	---	Binary signals and hardware detection
			Bit 0	Operation mode 2-stage
			Bit 1	Manual mode
			Bit 2	Binary input D1
			Bit 3	Binary input D2
			Bit 4	Thermostat function
			Bit 5	First controller output
			Bit 6	Second controller output
			Bit 7	Alarm relay
			Bit 13	Analog output available
			Bit 14	Interface available



## 12 Profibus-DP interface

### 12.1 RS-485 Technology transfer

Transmission is carried out in accordance with the RS-485 standard. This covers all areas in which high transmission speeds and simple, inexpensive installation technology are required. A twisted, shielded copper cable with a wire pair is used for this purpose.

The bus structure enables non-reacting coupling and decoupling of stations or gradual commissioning of the system. Subsequent extensions have no effect on stations that are already in operation.

A transmission speed of between 9.6 kbit/s and 12 Mbit/s can be selected. This is selected as a standard value for all devices on the bus during system commissioning.

Basic features

Network topology	Linear bus, active bus terminator at both ends, branching only permitted with baud rates of <1.5 Mbit/s
Medium	Shielded, twisted cable
Number of stations	32 stations in each segment without repeaters. With repeaters, can be extended to 126 (maximum of 9 repeaters permitted)
Connectors	Preferably 9-pin D-Sub connectors

Structure

All devices must be connected in a line structure. Up to 32 nodes (masters or slaves) may be interconnected within this kind of segment. If there are more than 32 nodes, repeaters must be used (to increase the number of devices, for example).

Cable length

The maximum cable length depends on the transmission speed. The cable length specified can be increased by using repeaters. It is recommended that you do not connect more than 3 repeaters in series.

Baud rate (kbit/s)	9.6	19.2	93.75	187.5	500	1500	12000
Range/segment	1200 m	1200 m	1200 m	1000 m	400 m	200 m	100 m

Range in relation to transmission speed.





Bus terminator

At the beginning and end of each segment, the bus is terminated by terminators. To enable fault-free operation, you must ensure that the two bus terminators are constantly supplied with power. The terminators are located in the Profibus connectors and can be activated by moving the slide switch to ON.




Figure 38: Bus terminator



## Cable data

The cable length specifications relate to cable type A described below:

Surge impedance	135...165 $\Omega$
Capacitance per unit length	<30 pf/m
Loop resistance	110 $\Omega$ /km
Cross-sectional area	>0.34 mm <sup>2</sup>

Preferably, a 9-pin D-Sub connector should be used for Profibus networks with RS-485 transmission technology. The pin assignments on the connector and the wiring specifications are listed at the end of this chapter.

Several manufacturers offer Profibus DP cables and connectors. Please consult the Profibus product catalog ([www.profibus.com](http://www.profibus.com)) for designations and reference addresses.



### Attention!

When connecting the devices, make sure you do not mix up the data lines. You must use shielded data lines. The braided shield and the foil shield underneath it (where applicable) should be connected at both sides and with a good conductive connection to protective ground.

Additionally, where possible you must ensure that data lines are laid separately from all power cables.

As an example of an appropriate cable, we recommend the following from Siemens:

Simatic Net Profibus 6XV1

Order no.: 830-0AH10

\* (UL) CMX 75 °C (Shielded) AWG 22 \*

## Data rate

With data rates of  $\geq 1.5$  Mbit/s, branching must be avoided during installation.



### Note!

For additional installation information, please refer to the Profibus DP installation guidelines (order no. 2.111) from the PNO.

Address:

Profibus Nutzorganisation e.V.

Haid- und Neu-Straße 7

76131 Karlsruhe

Internet: [www.profibus.com](http://www.profibus.com)

### Recommendation:

Please observe the installation information provided by the PNO, especially in cases where variable speed drives are being used simultaneously.

## Wiring and bus termination




Figure 39: Wiring and bus termination

Profibus DP is designed for fast data exchange at field level. In this case, the central control devices (such as the PLC/PC) communicate with distributed field devices (such as I/Os, screen recorders, and controllers) via a fast serial connection. Data exchange with these distributed devices is usually cyclical.

The communication functions required for this are defined by basic Profibus DP functions in accordance with IEC 61158 and IEC 61784.

## Basic functions

The central control device (master) reads input messages from the slaves cyclically and writes output messages to the slaves cyclically. The bus cycle time must be shorter than the program cycle time of the central PLC. As well as cyclical user data transfer, Profibus DP is able to carry out high-performance diagnostics and commissioning functions.

### Technology transfer

- RS-485 twisted 2-wire line
- Baud rate of 9.6 kbit/s upto 12 Mbit/s

### Bus access

- Master and slave devices, maximum 126 nodes on a bus (with repeater)

### Communication

- Point-to-point (user data traffic)
- Cyclical master-slave user data traffic

### Operation states

- Operate           Cyclical transfer of input and output data
- Clear             Inputs are read; outputs remain in a safe state
- Stop              Only master-master data transfer is possible

### Synchronization

- Sync-Mode       Not supported by the RWF55
- Freeze-Mode     Not supported by the RWF55

### Functionality

- Cyclical user data transfer between DP master and DP slave(s)
- Dynamic activation or deactivation of individual DP slaves
- Checking of DP slave configuration
- Address assignment for DP slaves via the bus
- Configuration of DP master via the bus
- Maximum 246 bytes of input/output data possible per DP slave

Protection functions

- Threshold monitoring for DP slaves
- Access protection for inputs/outputs of DP slaves
- Monitoring of user data traffic with adjustable monitoring timer for DP master

Device types

- DP master class 2, e.g., programming/configuration devices
- DP master class 1, e.g., central automation devices such as PLC, PC, etc.
- DP slave, e.g., devices with binary or analog inputs/outputs, controllers, recorders, etc.

Cyclical data traffic

Data traffic between the DP master and DP slaves is automatically processed by the DP master in a fixed, constantly recurring order. The user specifies the assignment of a DP slave to a DP master during bus system configuration. The DP slaves to be included in or excluded from cyclical user data traffic are also defined.

The data traffic between the DP master and DP slaves is divided into parameter setting, configuration, and data transfer phases. Before a DP slave is included in the data transfer phase, the DP master checks (in the parameter setting and configuration phase) whether the desired configuration that has been configured matches the actual device configuration.

As part of this check, the device type, format information, and length information as well as the number of inputs and outputs must match. As a result of this, the user is provided with reliable protection against parameter setting errors. As an addition to the user data transfer function that the DP master performs automatically, it is also possible to send new parameter setting data to the DP slaves if requested by the user.




Figure 40: User data transfer with Profibus DP



## 12.2 Wiring

Assignment of 9-pole D-SUB jack

COM2 D-SUB jack		Pin: Signal on the device terminal strip 1	Description
6		C1: VP	Power supply - plus
3		C2: RxD/TxD-P	Received data/transmission data - plus
8		C3: RxD/TxD-N	Received data/transmission data - minus
5		C4: DGND	Ground

## 12.3 Parameter list

Signal reference	Access	Data type	Parameter
X1	RO	Float	Analog input I nP1
X2	RO	Float	Analog input I nP2
SP1	R/W	Float	Setpoint 1
SP2 (dSP)	R/W	Float	Setpoint 2
---	RO	Word	Outputs and states
---	RO	Word	Binary signal and Hardware character
Pb1	R/W	Float	Proportional range 1
dt	R/W	Float	Derivative action time
r t	R/W	Float	Integral action time
REM	RO	Word	Status remote operation
X3	RO	Float	Analog input I nP3
AL	R/W	Word	Limit value alarm
B1	RO	Float	Burner alarm
WR	RO	Float	Actual setpoint





Note!

The respective address ranges are given in the \*.gsd file




## 13 What to do if ...

### 13.1 Alarm messages:

Display	Cause	Remedy
<p>9999 flashing</p> 	<p><b>Measured value exceeded limit</b> The measured value is too great, lies outside the measuring range, or the sensor is faulty (9999 flashing).</p> <p>-----</p> <p><b>Measured value dropped below limit</b> The measured value is too small, lies outside the measuring range, or the sensor has a short-circuit (-1999 flashing).</p>	<p>* Check to see if sensor and connecting line are damaged or have a short-circuit</p> <p>⇒ Reference! See chapter 4.3 <i>Assignment of pins</i></p> <p>* Check to see if the correct sensor is selected or connected</p> <p>⇒ Reference! See chapter 14.1.1 <i>Analog input InP1 (actual value)</i></p>
<p>The yellow communication symbol (top left) flashes</p> 	<p>Interface communication via Profibus, Modbus or PC software ACS411 (USB) is active</p>	<p>No remedy required, normal RWF55 behavior.</p>

### 13.2 Others

Display	Cause	Remedy
<p>On the upper display, the decimal place to the right is lit</p> 	<p>USB connection</p>	<p>Remove USB connection</p> <p>⇒ Reference! See chapter 10 <i>PC software ACS411</i></p>



## 14 Technical data

### 14.1 Inputs

#### 14.1.1 Analog input InP1 (actualvalue)

For resistance thermometers, thermal elements or standard signals with 2nd order digital filters (configurable).

Sampling time 250 ms

Resistance thermometers

Type	Measuring range	Measuring accuracy <sup>a</sup>	Impact of ambient temperature
Pt100; DIN EN 60751	-200...850 °C (-328...1562 °F)	≤0,05%	50 ppm/K
Pt1000; DIN EN 60751	-200...850 °C (-328...1562 °F)	≤0,05%	50 ppm/K
LG-Ni1000	-50...+160 °C (-58...320 °F)	≤0,05%	50 ppm/K
0...135 $\wedge$		≤0,05%	50 ppm/K

<sup>a</sup> Accuracies relate to the maximum measuring range.

Line resistance

Max. 30  $\wedge$  per line with 3-wire circuit

Line balancing

Not required with 3-wire circuits.

With 2-wire circuits, line balancing can be performed by making an actual value correction

Thermal elements

Type	Measuring range	Measuring accuracy <sup>a</sup>	Impact of ambient temperature
Fe-CuNi <b>J</b> DIN EN 60584	-200...+1200 °C (-328...+2192 °F)	≤0.25%	≤100 ppm/K
NiCr-Ni <b>K</b> DIN EN 60584	-200...+1372 °C (-328...+2502 °F)	≤0.25%	≤100 ppm/K
Cu-CuNi <b>T</b> DIN EN 60584	-200...+400 °C (-328...+752 °F)	≤0.25%	≤100 ppm/K
NiCrSi-NiSi <b>N</b> DIN EN 60584	-100...+1300 °C (-148...+2372 °F)	≤0.25%	≤100 ppm/K
Pt-RhPt <b>S</b> DIN EN 60584	-50...+1768 °C (-58...+3214 °F)	≤0.25%	≤100 ppm/K
Pt-RhPt <b>R</b> DIN EN 60584	-50...+1768 °C (-58...+3214 °F)	≤0.25%	≤100 ppm/K
Pt-RhPt <b>B</b> DIN EN 60584	0...1820 °C (32...3308 °F)	≤0.25%	≤100 ppm/K

<sup>a</sup> Accuracies relate to the maximum measuring range.

Cold-function temperature

Internal



Standard signals

Measuring range	Measuring accuracy <sup>a</sup>	Impact of ambient temperature
Voltage DC 0...5 V Input resistance RE >2 M $\Omega$	$\leq 0.2\%$	200 ppm/K
Voltage DC 0...10 V Input resistance RE >2 M $\Omega$	$\leq 0.1\%$	100 ppm/K
Voltage DC 1...5 V Input resistance RE >2 M $\Omega$	$\leq 0.2\%$	200 ppm/K
Current 0...20 mA Voltage drop $\leq 2$ V	$\leq 0.1\%$	100 ppm/K
Current 4...20 mA Voltage drop $\leq 2$ V	$\leq 0.1\%$	100 ppm/K

<sup>a</sup> Accuracies relate to the maximum measuring range.





### 14.1.2 Analog input InP2 (external setpoint, setpoint shifting)

Resistance measurement 0...1 k $\Omega$  or standard signals without

linearization. Sampling time 750 ms

Resistance thermometer

Resistance (2-wire circuit) 0...1 k $\Omega$  linear  
 $\leq 0.05\%$   
50 ppm/K

Standard signals

Measuring range	Measuring accuracy <sup>a</sup>	Impact of ambient temperature
Voltage DC 0...5 V Input resistance RE >2 M $\Omega$	$\leq 0.2\%$	200 ppm/K
Voltage DC 0...10 V Input resistance RE >2 M $\Omega$	$\leq 0.1\%$	100 ppm/K
Voltage DC 1...5 V Input resistance RE >2 M $\Omega$	$\leq 0.2\%$	200 ppm/K
Current 0...20 mA Voltage drop $\leq 2$ V	$\leq 0.1\%$	100 ppm/K
Current 4...20 mA Voltage drop $\leq 2$ V	$\leq 0.1\%$	100 ppm/K

<sup>a</sup> Accuracies relate to the maximum measuring range.

### 14.1.3 Analog input InP3 (outside temperature)

For resistance thermometers in 2-wire circuit, with fixed filter time constant.

Sampling time 6 s

Resistance thermometer

Type	Measuring range	Measuring accuracy <sup>a</sup>	Impact of ambient temperature
Pt1000 DIN EN 60751	-200...+850 °C (-328...+1562 °F)	$\leq 0.05\%$	50 ppm/K
LG-Ni1000	-50...+160 °C (-58...+320 °F)	$\leq 0.05\%$	50 ppm/K

<sup>a</sup> Accuracies relate to the maximum measuring range.

### 14.1.4 Binary input D1

Potentialfree contact for the following functions, depending on the configuration:

- No function
- Setpoint shifting
- Setpoint changeover
- Alarm input



### 14.1.5 Binary input D2

Potentialfree contact for operating mode changeover:

Burner modulating, if contacts D2 and DG are open	LED for <i>operating mode 2-stage</i> , <b>does not</b> light up on the front
Burner 2-stage, if contacts D2 and DG are closed	LED for <i>operating mode, 2-stage</i> , <b>lights up</b> on the front



## 14.2 Monitoring the measuring circuit

In the event of error, the outputs assume defined states (configurable).

Measuring transducer	Measured value crossed limit	Sensor/line has short-circuit	Sensor/line interrupted
Resistance thermometer	●	●	●
Thermal elements	●	---	●
Voltage			
DC 1...5 V	●	●	●
DC 0...5 V	(●)	---	---
DC 0...10 V	(●)	---	---
Current			
DC 4...20 mA	●	●	●
DC 0...20 mA	(●)	---	---

● = detected

(●) = detected only if measuring range is exceeded

--- = not detected

⇒ Reference!  
See chapter 13.1 *Alarm messages*.



## 14.3 Controller outputs OutP

Galvanic separation between supply voltage and analog inputs.

⇒ Reference!  
See chapter 4.2 *Galvanic separation*

### Relay K1 (NO contact) 1P, 1N (burner release)

Contact rating	Max. 2 A at AC 240 V at $\cos\phi > 0.6$
Contact life	250,000 switching cycles at high-fire
Contact protection	Varistor

<b>Power supply for transducer G+, G-</b>	DC 24 V $\pm 10\%$ /max. 30 mA, short-circuit-proof
---	---

The following relay data are those specified by the supplier.

### Relay K2, KQ (controlling element OPEN)

Contact rating	Max. 2 A at AC 240 V and $\cos\phi > 0.6$
Contact life	200,000 switching cycles at high-fire
Contact protection	RC combination

### Relay K3, KQ (controlling element CLOSE)

Contact rating	Max. 2 A at AC 240 V at $\cos\phi > 0.6$
Contact life	200,000 switching cycles at high-fire
Contact protection	RC combination

### Relay K6 (NO contact), 6P, 6N (multifunctional relay)

Contact rating	Max. 2 A at AC 240 V at $\cos\phi > 0.6$
Contact life	200,000 switching cycles at high-fire
Contact protection	Varistor

Relay data are those specified by the supplier.

### Analog output A+, A-

Voltage	DC 0...10 V short-circuit-proof
Load resistance	$R_{Last} \geq 500 \ \Omega$
Accuracy	$\leq 0.25\%$ , $\pm 50$ ppm/K
Current	0...20 mA/4...20 mA
Load resistance	$R_{Last} \leq 500 \ \Omega$
Accuracy	$\leq 0.25\%$ , $\pm 50$ ppm/K

Interface RS-485

Baudrate	4800 Baud 9600 Baud 19200 Baud 38400 Baud
Protocol	Modbus
Unit address	1...99

Profibus interface

Only present with RWF55.6!



## 14.4 Controller

Type of controller	3-position controller and continuous controller
Controller structure	P/PI/PD/PID
Sampling time	250 ms

## 14.5 Electrical data

Power supply (switching network section)	AC 110...240 V +10/-15% 48...63 Hz
Electrical safety	To DIN EN 60730, part 1 Overvoltage category III Degree of contamination 2
Safety class I	With internal separation from SELV electrical circuits
SELV voltage	Max. 30 V
Power consumption	Max. 20 VA
Data backup	EEPROM
Electrical connection	At the rear via screw terminals
- Cross-sectional area	0.25...1.5 mm <sup>2</sup> fine-wired
- Stranded wire with	- Ferrules to DIN 46228 - Pin-type cable socket to DIN 46231 - Crimp-type cable socket in fork-form for M3 thread (dimensions to DIN 46237)
With UL applications	Use of the cable lug or ferrules to UL486A-B (UL listed or recognized)
Tightening torque	0.5 Nm
Electromagnetic compatibility	DIN EN 61326-1
Emitted interference	Class B
Immunity	Meeting industrial requirements

## 14.6 Housing

Type of housing	Made of Makrolon for control panel mounting to DIN IEC 61554 (use in indoor)
Color	Light-grey RAL7035
Mounting depth	122 mm
Mounting position	Optional
Degree of protection	To DIN EN 60529 Front side IP66 Rear IP20
	To UL50E and to NEMA 250 Front side type 5
Weight	(Fully equipped)
- RWF55.5	Approx. 329 g
- RWF55.6	Approx. 342 g



## 14.7 Environmental conditions

<b>Storage</b>	DIN IEC 60721-3-1
Climatic conditions	Class 1K3
Mechanical conditions	Class 1M2
Temperature range	-40...70 °C
Humidity	<95% r.h.
<b>Transport</b>	DIN IEC 60721-3-2
Climatic conditions	Class 2K2
Mechanical conditions	Class 2M2
Temperature range	-40...70 °C
Humidity	<95% r.h.
<b>Operation</b>	DIN IEC 60721-3-3
Climatic conditions	Class 3K3
Mechanical conditions	Class 3M3
Temperature range	-20...50°C
Humidity	<95% r.h.
Installation altitude	Max. 2000 m above sea level

**Attention!**

Condensation, formation of ice and ingress of water are not permitted!

## 14.8 Segment display

Height of numerals	
- Upper display	10 mm
- Lower display	7 mm
Color	
- Upper display	Red
- Lower display	Green
Digits	4 (including 0, 1 or 2 decimal places, configurable)
Range of display	-1999...9999



## 14.9 Standards and certificates



### Applied directives:

- Low-voltage directive 2014/35/EC
- Electromagnetic compatibility 2014/30/EC

Compliance with the regulations of the applied directives is verified by the adherence to the following standards / regulations:

Temperature control devices and temperature limiters for heat generating systems	DIN EN 14597
Automatic electrical controls for household and similar use Part 1: General requirements	DIN EN 60730-1
Automatic electrical controls for household and similar use Part 2-9: Particular requirements for temperature sensing controls	DIN EN 60730-2-9
Electrical equipment for measurement, control and laboratory use - EMC requirements Part 1: General requirements	DIN EN 61326-1

**The relevant valid edition of the standards can be found in the declaration of conformity!**



EAC Conformity mark (Eurasian Conformity mark)



ISO 9001:2008  
ISO 14001:2004  
OHSAS 18001:2007



China RoHS  
Hazardous substances table:  
<http://www.siemens.com/download?A6V10883536>



## 15 Key

A	Switch-on point for high-fire when response threshold (q) is reached
ACrA	Response by Out of Range
Adr	Device address Modbus
AF	Alarm function
AL	Limit value
At1	Outside temperature 1
At2	Outside temperature 2
B	Switch-off point for burner
bdr t	Baudrate
b i n1	Binary input 1 b
i n2	Binary input 2 b i
nF	Binary input
CACt	Operating action
Cntr	Controller
CodE	Level lockout
ConF	Configuration
CtYP	Controller type
db	Dead band
dECP	Decimal point
dF1	Filter time constant dF2
Filter	time constant dF3
Filter	time constant dFt
Data	format
diSL	Lower display
diSP	Display
diSU	Upper display
dSP	Setpoint
dt	Derivative action time
dt t	Remote Detection Timer
End	End value
FnC2	Function
FnC3	Function
FnCt	Function
Ht1	Boiler temperature 1
Ht2	Boiler temperature 2
HYS1	Switch-on threshold heating controller
HYS2	Switch-off threshold heating controller
HYS3	Switch-off threshold heating controller
HYS4	Switch-on threshold cooling controller
HYS5	Switch-off threshold cooling controller
HYS6	Switch-off threshold cooling controller
HYS t	Switching difference
InP	Analog input
InP1	Analog input 1 (actual value)
InP2	Analog input 2 (external setpoint or setpoint shifting)
InP3	Analog input 3 (outside temperature)
IntF	Interface
OFF1	Correction of measured value
OFF2	Correction of measured value
OFF3	Correction of measured value
oLHi	Upper working range limit oLLo
	Lower working range limit
OPnt	Zero point
OPr	User
OutP	Control outputs





PArA	Parameter
Pb	Proportional range
Pb1	Proportional range 1
q	Response threshold
qeff	Sum of all integrals
rAFC	Thermal shock protection
rAL	Limit value
rASL	Ramp slope
rOut	Value when out of range
rt	Integral action time
SCH1	End of display SCH2
	End of display
SCL1	Start of display
SCL2	Start of display
SEn1	Sensor type
SEn2	Sensor type
SEn3	Sensor type
SiGn	Signal type
SP1	Setpoint 1
SP2	Setpoint 2
SPH	Setpoint limitation end
SPL	Setpoint limitation start
t	Time
t1	Power ON (startup at actual value)
t2	Actual value of ramp stop outside tolerance band
t3	Actual value returned to tolerance band
t4	Setpoint reached, thermal shock protection (TSS) no longer active
toLP	Tolerance band of ramp
tout	Timeout
tt	Running time of controlling element
Unit	Unit of temperature
W	Setpoint
Y	Angular positioning



## 16 List of figures

Figure 1: Block structure .....	12
Figure 2: Dimensions of RWF55 .....	14
Figure 3: Mounting in a panel cutout .....	15
Figure 4: Test voltages.....	18
Figure 5: Assignment of terminals .....	19
Figure 6: Control sequence of heating controller.....	22
Figure 7: Control sequence of cooling controller .....	22
Figure 8: Control sequence of modulating burner, 3-position output.....	23
Figure 9: Control sequence of modulating burner, analog output.....	24
Figure 10: Control sequence of 2-stage burner, 3-position output .....	25
Figure 11: Control sequence of 2-stage burner, analog output .....	26
Figure 12: Setpoint changeover or setpoint shift .....	29
Figure 13: Setpoint changeover SP1 / external setpoint.....	30
Figure 14: Setpoint shifting analog / binary .....	31
Figure 15: External setpoint, setpoint shifting binary via dSP.....	32
Figure 16: Heating curve slope .....	33
Figure 17: Control sequence response threshold (q) .....	34
Figure 18: Control sequence <i>Cold start of plant</i> .....	35
Figure 19: Thermal shock protection (TSS).....	37
Figure 20: Meaning of display and buttons.....	38
Figure 21: Display start .....	40
Figure 22: Basic display .....	40
Figure 23: Display of self-setting function.....	44
Figure 24: Display of software version .....	45
Figure 25: Display segment test.....	45
Figure 26: Parameterization .....	46
Figure 27: Configure .....	49
Figure 28: Alarm function lk1...lk6 .....	56
Figure 29: Alarm function lk7 and lk8 .....	56
Figure 30: Self-setting function in high-fire operation .....	62
Figure 31: Great difference between actual value and setpoint .....	63
Figure 32: Small control deviation .....	63
Figure 33: Pb too small .....	64
Figure 34: Pb too large.....	64
Figure 35: r t, dt too small.....	64



Figure 36: r t, dt too large .....	64
Figure 37: Optimum adjustment .....	64
Figure 38: Bus terminator .....	73
Figure 39: Wiring and bus termination.....	75
Figure 40: User data transfer with Profibus DP .....	76
Figure 41: COM2 D-SUB jack.....	77



## Index

<b>A</b>		
<b>ACS411</b>		
Changing the parameters .....	65	
Installation .....	67	
Languages .....	66	
License and liability regulations .....	66	
Others .....	67	
PC software ACS411 .....	65	
Place of installation .....	66	
Prerequisites for hardware .....	66	
Procurement of PC software ACS411 .....	66	
Safety notes .....	65	
Setting the correct system parameters .....	65	
Alarm function AF		
Limit value AL relative to setpoint .....	56	
<b>C</b>		
Changing setpoint		
SP2 .....	41	
Changing the setpoint		
SP1 .....	41	
<b>Configuration</b>		
Alarm function AF .....	56	
Analog input InP1 .....	50	
Analog input InP2 .....	52	
Analog input InP3 .....	53	
Analog output .....	58	
Binary functions binF .....	59	
Binary output .....	58	
Control outputs OutP .....	58	
Controller Cntr .....	54	
Display diSP .....	60	
Interface IntF .....	61	
Thermal shock protection (TSS) rAFC .....	55	
Configuration ConF .....	49	
<b>D</b>		
<b>Description</b>		
Interface .....	11	
Option .....	11	
<b>E</b>		
<b>Electrical connection</b>		
Connection of external components .....	17	
<b>Electrical connections</b> .....	17	
Assignment of terminals .....	19	
Fusing .....	17	
Galvanic separation .....	18	
Incorrect use .....	17	
Installation notes .....	17	
Safety regulations .....	17	
Screw terminals .....	17	
Suppression of interference .....	17	
<b>I</b>		
<b>Identification of product no.</b> .....	13	
Location .....	13	
Product nos .....	13	
Scope of delivery .....	13	
Type field .....	13	
<b>Installation</b> .....	14	
Cleaning the front .....	16	
Dimensions .....	14	
Installation site and climatic conditions .....	14	
Mounting the controller in a panel cutout .....	15	
Removing the controller from the panel cutout .....	16	
Side-by-side mounting .....	15	
<b>Introduction</b> .....	8	
Block structure .....	12	
Control .....	11	
Cooling controller .....	11	
Correct use .....	9	
Description .....	11	
General notes .....	8	
Mounting .....	11	
Notification symbols .....	10	
Presentation .....	10	
Qualified personnel .....	9	
Safety notes .....	9	
Typographical conventions .....	9	
Use in heating plants .....	11	
Warning symbols .....	9	
<b>K</b>		
<b>Key</b> .....	88	
<b>M</b>		
<b>Modbus interface</b> .....	68	
Configuration level .....	70	
Device data .....	71	
Device state .....	71	
Parameter level .....	69	
Remote operation .....	70	
User level .....	68	
<b>O</b>		
<b>Operating mode</b>		
Output .....	24	
<b>Operating modes</b> .....	22	
2-stage burner, 3-position output .....	25	
2-stage burner, analog output .....	26	
Burner shutdown .....	27	
Cold start of plant .....	35	
Cooling controller .....	22, 24, 26, 34, 36	
External setpoint, setpoint shifting binary via dSP .....	32	
Heating controller .....	22, 35	
Heating curve .....	33	
High-fire operation .....	23	
Interlocking .....	35, 37	
Low-fire operation .....	22	
Modulating burner, 3-position output .....	23	



Modulating burner, analog output .....	24	Wiring.....	77
Operating mode changeover .....	23	<b>R</b>	
Predefined setpoint .....	28	RS-485 Technology transfer	
Response threshold (q) .....	34	Basic features .....	72
Setpoint changeover SP1 / external setpoint via InP2 .....	30	Basic functions.....	75
Setpoint changeover SP1 / SP2 or setpoint shift analog via InP2.....	29	Bus terminator .....	73
Setpoint shifting SP1 analog via InP2/ binary via dSP.....	31	Cable data .....	74
Thermal shock protection.....	37	Cable length.....	72
Thermostat function .....	22	Cyclical data traffic.....	76
Weather-compensated setpoint shifting .....	33	Data rate .....	74
<b>Operation .....</b>	<b>38</b>	Structure .....	72
3-position controller .....	42	Wiring and bus termination .....	75
Basic display.....	40	<b>S</b>	
Basic display.....	38	Self-setting function .....	62
Cancel .....	44	2 procedures .....	63
Changing the setpoints.....	41	Checking the controller parameters .....	64
Display of software version .....	45	Conditions .....	63
Flashing actual value display .....	39	Self-setting function in high-fire operation .....	62
Initialization .....	38	<b>T</b>	
Manual control .....	39	Technical data .....	79
Manual control, 2-stage burner .....	43	Binary input D2 .....	82
Manual control, modulating burner .....	42	Controller.....	85
Meaning of display and buttons.....	38	Controller outputs OutP.....	84
Modulating controller .....	42	Electrical data .....	85
Parameter display.....	38	Environmental conditions.....	86
Segment test .....	45	Housing .....	85
Self-setting function .....	38	Inputs .....	79
Start .....	44	Monitoring the measuring circuit .....	83
Starting the self-setting function .....	44	Resistance thermometers .....	79
Timeout.....	41	Segment display .....	86
User level.....	41	Standard signals .....	80
<b>P</b>		Standards and certificates .....	87
Parameterization		<b>Technical Data</b>	
Display of controller parameters .....	47	Analog input InP1 .....	79
Parameterization PArA .....	46	Analog input InP2 .....	81
<b>PC software ACS411</b>		Analog input InP3 .....	81
Measuring accuracy .....	67	Binary input D1 .....	81
Operating systems .....	66	Interface RS-485.....	84
Powering the controller via the USB port.....	67	Profibus interface .....	84
Use of USB port .....	67	Resistance thermometer.....	81
Using the HUB.....	67	Standard signals .....	81
<b>PC-Software ACS411</b>		Thermal elements .....	79
Switching off .....	67	<b>W</b>	
<b>Profibus-DP interface .....</b>	<b>72</b>	What to do if .....	78
Parameter list.....	77	Alarm messages .....	78
RS-485 Technology transfer .....	72	Others .....	78
		<b>Wiring</b>	
		Assignment of 9-pole D-Sub jack.....	77



บริษัท เอดีดี เฟอร์เนส จำกัด

ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

<https://www.add-furnace.com> E-mail: [sales@add-furnace.com](mailto:sales@add-furnace.com)

Siemens AG Infrastructure & Cities Sector Building Technologies Division  
Berliner Ring 23  
D-76437 Rastatt  
Tel. +49 7222 598 279  
Fax +49 7222 598 269  
[www.siemens.com](http://www.siemens.com)

© 2017 Siemens AG Infrastructure & Cities Sector  
Building Technologies Division  
Subject to change!

94/94