




How to Set Shimaden SR90 EV1 or EV2



How to Set Shimaden SR90 Input Type



How to Set Shimaden SR90 4-20mA Output 95% Limit



SERVED THE RIGHT OF THIS DRAWING BY ABB FURNACE CO.,LTD.
DO NOT COPY OR REPEAT THIS DRAWING BEFORE GETTING CONSENT FROM COMPANY




ABB FURNACE CO.,LTD.
 44 8032000000 20 0000000000 0000000000 0000000000 0000000000
 http://www.abb-furnace.com sales@abb-furnace.com
 Tel: +66(0)8-08-170-170 Fax: +66(0)2-6888-3258

Itemref	Quantity	Title/Name, designation, material, dimension etc	Article No./Reference
Designed by XIE	Checked by HAI_BY	Approved by - date FENG_BY_10/02/17	File name ABB-FURNACE
CUSTOMER		Scale(A4) 1:X	Edition 0
ABB FURNACE CO.,LTD.		Sheet 1/1	View(Khr-d)