


### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

# JCR-33A, JCD-33A INSTRUCTION MANUAL









### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## **Preface**

Thank you for purchasing our Digital Indicating Controller JCR-33A or JCD-33A. This manual contains instructions for the mounting, functions, operations and notes when operating the JCR-33A and JCD-33A. To prevent accidents arising from the misuse of this controller, please ensure the operator receives this manual.

### Abbreviations used in this manual

Symbol	Term
PV	Process variable
SV	Desired value
MV	Output manipulated variable
OUT1	Control output 1
OUT2	Control output 2 (optional)
AT	Auto-tuning

### **Characters used in this manual**

Indication	-;	0	-	2	3	닉	5	5	7	8	3	٤	F	
Number, ℃/℉	-1	0	1	2	3	4	5	6	7	8	9	℃	°F	
Indication	Я	Π	ь		ರ	Ε	F	5	H		J	E	Ŀ	ň
Alphabet	1	٨	В	С	D	Е	F	G	Н	1	J	K	L	М
Indication	n	0	P	9	r	٦	r	U	Ħ	ũ	Ä	H	1	
Alphabet	N	0	Р	Q	R	S	Т	U	V	W	Х	Υ	Z	



### **ADD FURNACE CO.,LTD.**

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ข 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## **Notes**

- This instrument should be used in accordance with the specifications described in the manual. If it is not used according to the specifications, it may malfunction or cause a fire.
- Be sure to follow the warnings, cautions and notices. If they are not observed, serious injury or malfunction may occur.
- Specifications, external appearance of the JCR-33A and JCD-33A and the contents of this instruction manual are subject to change without notice.
- Care has been taken to assure that the contents of this instruction manual are correct, but if there are any doubts, mistakes or questions, please inform our sales department.
- Measures must be taken to ensure that the operator cannot touch power terminals or other high voltage sections.
- Any unauthorized transfer or copying of this document, in part or in whole, is prohibited.
- Shinko Technos CO., LTD. is not liable for any damage or secondary damage(s) incurred as are result of using this product, including any indirect damage.

### SAFETY PRECAUTIONS(Be sure to read these precautions before using our products.)

The safety precautions are classified into categories: "Warning" and "Caution".

Depending on the circumstances, procedures indicated by Caution may be linked to serious results, so be sure to follow the directions for usage



Procedures which may lead to dangerous conditions and cause death or serious injury, if not carried out properly.



Procedures which may lead to dangerous conditions and cause superficial to medium injury or physical damage or may degrade or damage the product, if not carried out properly.

## Ŵ

## Warning

- To prevent an electric shock or fire, only Shinko or other qualified service personnel may handle the inner assembly.
- To prevent an electric shock, fire or damage to the instrument, parts replacement may only be undertaken by Shinko or other qualified service personnel.

## Ŵ

## Safety precautions

- To ensure safe and correct use, thoroughly read and understand this manual before using this instrument.
- This instrument is intended to be used for industrial machinery, machine tools and measuring equipment. Verify correct usage after purpose-of-use consultation with our agency or main office. (Never use this instrument for medical purposes with which human lives are involved.)
- External protection devices such as protective equipment against excessive temperature rise, etc. must be installed, as malfunction of this product could result in serious damage to the system or injury to personnel. Also proper periodic maintenance is required.
- This instrument must be used under the conditions and environment described in this manual. Shinko Technos Co., Ltd. does not accept liability for any injury, loss of life or damage occurring due to the instrument being used under conditions not otherwise stated in this manual

### **Caution with respect to Export Trade Control Ordinance**

To avoid this instrument from being used as a component in, or as being utilized in the manufacture of weapons of mass destruction (i.e. military applications, military equipment, etc.), please investigate the end users and the final use of this instrument. In the case of resale, ensure that this instrument is not illegally exported.

,



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ข 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

## 1.Installation precautions

## **Caution**

This instrument is intended to be used under the following environmental conditions (IEC61010-1): Overvoltage category, Pollution degree 2Ensure the mounting location corresponds to the following conditions:

- · A minimum of dust, and an absence of corrosive gases
- · No flammable, explosive gases
- No mechanical vibrations or shocks
- No exposure to direct sunlight, an ambient temperature of 0 to 50(32 to 122) that does not change rapidly, and no icing
- An ambient non-condensing humidity of 35 to 85%RH
- No large capacity electromagnetic switches or cables through which large current is flowing
- No water, oil or chemicals or where the vapors of these substances can come into direct contact with the unit
- If JCD-33A or JCR-33A is mounted through the face of a control panel, the ambient temperature of the unit not the ambient temperature of the control panel must be kept to under 50, otherwise the life of electronic parts (especially electrolytic capacitors) of the unit will be shortened.

**Note** •Do not install this instrument on or near flammable material even though the case of this instrument is made of flame-resistant resin.

## 2. Wiring precautions

## <u>/!\</u>

## **'**∖ Caution

- Do not leave wire remnants in the instrument, because they could cause a fire and/or a malfunction.
- Use a solderless terminal with an insulation sleeve in which an M3 screw fits when wiring the JCD-33A or JCR-33A.
- The terminal block of this instrument is designed to be wired from the left side. The lead wire must be inserted from the left side of the terminal, and fastened with the terminal screw.
- Tighten the terminal screw using the specified torque.

If excessive force is applied to the screw when tightening, the screw or case may be damaged.

- Do not apply a commercial power source to the sensor connected to the input terminal or allow the power source to come into contact with the sensor, as the input circuit may be burnt out.
- This controller has no built-in power switch, circuit breaker or fuse. It is necessary to install a power switch, circuit breaker or fuse near the controller.

(Recommended fuse: Time-lag fuse, rated voltage 250V AC, rated current 2A)

• For a 24V AC/DC of power source, do not confuse polarity when using a direct current (DC).

## 3. Operation and maintenance precautions



## **Caution**

- It is recommended that AT be performed during the trial run.
- Do not touch live terminals. This may cause electric shock or problems in operation.
- Turn the power supply to the instrument OFF before retightening the terminal and cleaning. Working on or touching the terminal with the power switched ON may result in severe injury or death due to electric shock.
- Use a soft, dry cloth when cleaning the instrument.(Alcohol based substances may tarnish or deface the unit.)
- As the display section is vulnerable, do not strike or scratch it with a hard object or press hard on it.

## ADD

## บริษัท เอดีดี เฟอร์เนส จำกัด

### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ช 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

## ---CONTENTS---

1. Model	
1.1 Model	
1.2 Rated input	
1.3 How to read the model label	7
2. Name and functions of sections	
3. Mounting to the control panel	
3.1 Site selection	
3.2 External dimensions	
3.3 Panel cutout	
3.4 CT (current transformer) external dimensions	11
3.5 Mounting (Common to JCR-33A and JCD-33A)	11
4. Wiring	
4.1 Terminal arrangement	12
4.2 Wiring example	
5. Setup	
5.1 Operation flowchart	16
5.2 Main setting mode	18
5.3 Sub setting mode	18
5.4 Auxiliary function setting mode 1	21
5.5 Auxiliary function setting mode 2	22
5.6 Control output OFF function	27
5.7 Auto/Manual control switching function	27
5.8 MV indication	
6. Operation	28
7. Action explanation	
7.1 OUT1 action	_
7.2 Heater burnout alarm action (option)	29
7.3 OUT1 ON/OFF control action	
7.4 OUT2 (Heating/Cooling control) action (option)	31
7.5 A1 and A2 action	
7.6 SV1/SV2 external selection	35
8. Control action explanations	
8.1 PID	35
8.2 AT of this controller	
8.3 Auto-reset (offset correction)	37
9. Specifications	
9.1 Standard specifications	
9.2 Optional specifications	42
10. Troubleshooting	
10.1 Indication	
10.2 Key operation	
10.3 Control	
11. Character table	46



### ADD FURNACE CO.,LTD.


44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furn</u>ace.com

## 1. Model

### 1.1 Model

Series name, Control output (OUT1), input and option code, etc are entered where underlined.



Standard specifications

Otarida	tandard specifications									
J C□-3 3 A -□/□ □										
Series	R						JCR-33A: W48 x H96 x D110mm			
name	D						JCD-33A: W96 x H96 x D110mm			
Alarm 1 (A1) A				Alarm type can be selected by keypad. *1						
Control	ΔIJ	tnu	t	R			Relay contact			
(OUT1)		ipu		S			Non-contact voltage (for SSR drive)			
(0011)			Α			DC current				
Input					M		Multi-range *2			
					100 to 240V AC (standard)					
Supply voltage				1	24V AC/DC *3					

<sup>\*1: 9</sup> types of alarm action, No alarm action and Energized/De-energized can be selected by keypad.

**Optional specifications** 

Code	Name									
A2	Alarm 2 (A2) *1, *2	larm 2 (A2) *1, *2								
W	Heater burnout Alarm *2,	*3								
DR	Heating/Cooling	Relay contact output *2								
DS	_control output (OUT2)	Non-contact voltage output *2								
DA		DC current output *2								
C5	Serial communication (RS	S-485) *4								
LA	Loop break alarm *1									
P24	Insulated power output *5									
BK	Color: Black									
TC	Terminal cover									

<sup>\*1:</sup> When A2 and LA output are added together, they utilize common output terminals.

<sup>\*2:</sup> Input types (10 thermocouple, 2 RTD, 2 DC current and 4 DC voltage types) can be selected by keypad.

<sup>\*3: 100</sup> to 240V AC is standard specification for the supply voltage. However, when ordering 24V AC/DC, enter "1" after the input code.

<sup>\*2:</sup> Only 2 options can be added from A2 output, Heater burnout alarm output and Heating/Cooling control output.

<sup>\*3:</sup> For DC current output type, Heater burnout alarm output cannot be added.

<sup>\*4:</sup> If Serial communication is added, the SV1/SV2 external selection (standard function)will be disabled.

<sup>\*5:</sup> If the Insulated power output is added, Heating/Cooling control output and Heater burnout alarm output cannot be added.



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

1.2 Rated input


Input type		Input range	Resolution
K	−200 to 1370°C	<b>–320 to 2500</b> °F	1°C(°F)
	−199.9 to 400.0 °C	<b>–199.9 to 750.0</b> °F	0.1°C(°F)
J	−200 to 1000 °C	−320 to 1800 °F	1°C(°F)
R	<b>0 to 1760</b> °C	0 to 3200 °F	1°C(°F)
S	<b>0 to 1760</b> °C	0 to 3200 °F	1°C(°F)
В	<b>0 to 1820</b> °C	0 to 3300 °F	1°C(°F)
E	<b>−200 to 800</b> °C	−320 to 1500 °F	1°C(°F)
Т	−199.9 to 400.0 °C	−199.9 to 750.0 °F	0.1°C(°F)
N	−200 to 1300 °C	<b>–320 to 2300</b> °F	1°C(°F)
PL- II	<b>0 to 1390</b> °C	0 to 2500 °F	1°C(°F)
C(W/Re5-26)	<b>0 to 2315</b> °C	0 to 4200 °F	1°C(°F)
Pt100	−199.9 to 850.0 °C	<b>–199.9 to 999.9</b> °F	0.1°C(°F)
JPt100	−199.9 to 500.0 °C	<b>–199.9 to 900.0</b> °F	0.1°C(°F)
Pt100	<b>−200 to 850</b> °C	<b>–300 to 1500</b> °F	1°C(°F)
JPt100	<b>−200 to 500</b> °C	<b>–300 to 900</b> °F	1°C(°F)
4 to 20mA DC	-1999 to 9999 *1, *2		1
0 to 20mA DC	-1999 to 9999 *1, *2		1
0 to 1V DC	-1999 to 9999 *1		1
0 to 5V DC	-1999 to 9999 *1		1
1 to 5V DC	-1999 to 9999 *1	<u> </u>	1
0 to 10V DC	-1999 to 9999 *1		1

<sup>\*1:</sup> For DC input, input range and decimal point place can be changed.

### 1.3 How to read the model label

Model labels are attached to the case and the inner assembly.

When the supply voltage is 24V AC/DC, "1" is entered before the option code.



(1): Model, (2): Option, (3): Serial number

<sup>\*2:</sup> Connect  $50\Omega$  shunt resistor (sold separately) between input terminals.




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## 2. Name and functions of sections



(Fig. 2-1)

### (1) PV display

Indicates the PV or setting characters in the setting mode with the red LED.

### (2) SV display

Indicates the SV, the MV or each set value in the setting mode with the green LED.

During manual control, the MV flashes in the SV Display.

While the MV is indicated, the last point on the right flashes.

### (3) SV1 indicator

When SV1 is selected, the green LED lights.

### (4) SV2 indicator

When SV2 is selected, the yellow LED lights.

### (5) OUT1 indicator

When OUT1 is ON, the green LED lights.(In the case of DC current output type, it flashes in 250ms cycles corresponding to the MV.)

### (6) OUT2 indicator

When OUT2 is ON, the yellow LED lights.(In the case of DC current output type, it flashes in 250ms cycles corresponding to the MV.)

### (7) HB indicator

When Heater burnout alarm output or Sensor burnout alarm output is ON, the red LED lights.(When Heater burnout Alarm is added, the red LED also lights when indication is overscale or underscale.)

### (8) AT indicator

When AT or Auto-reset is active, the yellow LED flashes.

### (9) TX/RX indicator

The yellow LED lights during Serial communication TX (transmitting).

### (10) A1 indicator

When A1 output is ON, the red LED lights.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### (11) A2/LA indicator

When A2 output or LA output is ON, the red LED lights.

### (12) Increase Key $(\triangle)$

Increases numeric values.

## (13) Decrease Key ( $\nabla$ )

Decreases numeric values.

### (14) Mode Key (<sup>(2)</sup>)

Switches the setting mode and registers the set (or selected) value.

[Set (or selected) value are registered by pressing the Mode Key.]

### (15) OUT/OFF Key (<sup>(1)</sup>)

Switches Control output OFF or Auto/Manual control.

To release the Control output OFF function, press this key for approx. 1 sec.

•If Control output OFF function is selected during OUT/OFF Key function selection mode, the control output can be turned on or off.

Once the Control output OFF function is enabled, the function cannot be released even if the power to the instrument is turned OFF and turned ON again.

To cancel the function, press the key again for approx. 1 second.

•If Auto/Manual control function is selected during OUT/OFF Key function selection, automatic control is performed when the power to the controller is turned on. In this status, if the key is pressed, the automatic control is switched to manual control and vice versa.

Auto/Manual control can be switched only in the PV/SV display mode.



## **Notice**

When setting the specifications and functions of this controller, connect terminals 2 and 3 for power source first, then set them referring to "5. Setup" before performing "3. Mounting to the control panel" and "4. Wiring".

## 3. Mounting to the control panel

### 3.1 Site selection

This instrument is intended to be used under the following conditions (IEC61010-1):

Overvoltage II category, Pollution degree 2Ensure the mounting location corresponds to the following conditions:

- (1) A minimum of dust, and an absence of corrosive gases
- (2) No flammable, explosive gases
- (3) No mechanical vibrations or shocks
- (4) No exposure to direct sunlight, an ambient temperature of 0 to 50(32 to 122) that does not change rapidly, and no icing
- (5) An ambient non-condensing humidity of 35 to 85%RH
- (6) No large capacity electromagnetic switches or cables through which large current is flowing
- (7) No water, oil or chemicals or where the vapors of these substances can come into direct contact with the unit
- (8) If JCD-33A or JCR-33A is mounted through the face of a control panel, the ambient temperature of the unit not the ambient temperature of the control panel must be kept to under 50 °C, otherwise the life of electronic parts (especially electrolytic capacitors) of the unit will be shortened.




### ADD FURNACE CO.,LTD.


44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## 3.2 External dimensions (Scale: mm) •JCR-33A




### • JCD-33A



### 3.3 Panel cutout (Scale: mm)

### • JCR-33A



(Fig. 3.3-1)




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

warranties will be invalidated.

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

• JCD-33A





(Fig. 3.3-2)

### 3.4 CT (Current transformer) external dimensions (Scale: mm)

CTL-6S (for 5A, 10A, 20A)

CTL-12-S36-10L1U (for 50A)





(Fig. 3.4-1)

### 3.5 Mounting (Common to JCR-33A and JCD-33A)

## $\bigwedge$

## **Caution**

As the case is made of resin, do not use excessive force while screwing in the mounting bracket, or the case could be damaged.

The torque should be 0.12N•m

Mount the controller vertically to the flat, rigid panel to ensure it adheres to the Drip-proof/Dust-proof specification (IP66).

Mounting panel thickness: 1 to 8mm

Insert this unit from the front side of the panel.

Attach the mounting brackets by the holes at the top and bottom of the case, and secure the controller in place with the screws.


Refer to (Fig. 3.5-1).



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com



## 4. Wiring



## Warning

Turn the power supply to the instrument off before wiring or checking. Working on or touching the terminal with the power switched on may result in severe injury or death due to electric shock.

Moreover, the instrument must be grounded before the power supply to the instrument is turned on.

## À

## **Caution**

- The terminal blocks of the JCR-33A and JCD-33A are designed to be wired from the left side. The lead wire must be inserted from the left side of the terminal, and fastened with the terminal screw.
- Dotted lines are optional. Option terminals are equipped only when the option is ordered.
- When A2 (option) and Heater burnout alarm (option) are added together, use terminals 12-13 for A2, and 9-10 for Heater burnout alarm.
- When Heating/Cooling control (option) and Heater burnout alarm (option) are added together, use terminals 9-10 for the Heating/Cooling control and 12-13 for the Heater burnout alarm.
- When only Heater burnout alarm option is added, use terminals 9 and 10.
- When A2 (option) and LA (option) are added, they utilize common output terminals.
- If the Insulated power output (option) is added, Heating/Cooling control (option) and Heater burnout alarm (option) cannot be added
- Lead wire solderless terminal Use a solderless terminal with an insulation sleeve in which an M3 screw fits as shown below. The torque should be 0.63N·m.


Solderless terminal	Manufacturer	Model	Tightening torque
Y type	Nichifu Terminal Industries CO.,LTD	TMEV1.25Y-3	
	Japan Solderless Terminal MFG CO.,LTD.	VD1.25-B3A	0.63N•m
Ring type	Nichifu Terminal Industries CO.,LTD.	TMEV1.25-3	
	Japan Solderless Terminal MFG CO.,LTD.	V1.25-3	




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com



### 4.1 Terminal arrangement



4.2 Wiring example



## **Caution**

- Use a thermocouple and compensating lead wire according to the sensor input specifications of this controller.
- Use the 3-wire RTD system according to the sensor input specifications of this controller.
- This controller has no built-in power switch circuit breaker or fuse. It is necessary to installa power switch, circuit breaker or fuse near the controller.

(Recommended fuse: Time-lag fuse, rated

voltage 250V AC, rated current 2A)

- For a 24V AC/DC of power source, do not confuse polarity when using a direct current(DC).
- •When using a relay contact output type, externally use a relay according to the load capacity to protect the built-in relay contact.

(Fig. 4.1-1)

- When wiring, keep input wires (thermocouple, RTD, etc.) away from AC sources or load wires.
- Use a thick wire (1.25 to 2.0mm<sub>2</sub>) for grounding.




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

### [JCR-33A-R/E]




\*To prevent the unit being damaged by the harmful effects of unexpected high level noise, it is recommended that a surge absorber be installed between the electromagnetic switch coils.

- For a 24V AC/DC of power source, do not confuse polarity when using a direct current (DC).
- Number of connectable units in parallel when using Shinko SSR:

SA-400 series: 5 units SA-500 series: 2 units

## Heater burnout alarm output] (1)This alarm is not usable for detecting heater current under phase control.

- (2) Use current transformer (CT) provided, and pass one lead wire of heater circuit into the hole of the CT.
- (3) When wiring, keep CT wire away from any AC sources and load wires to avoid the external interference





### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## 5. Setup

For the thermocouple and RTD input, the sensor input characters and temperature unit are indicated in the PV display, and the input range high limit value is indicated in the SV display for approximately 3 seconds after the power is turned on. (Table 5-1)

For DC input, the sensor input characters are indicated in the PV display and the scaling high limit value is indicated in the SV display for approximately 3 seconds after the power is turned on. (Table 5-1) If any other value is set during the scaling high limit setting mode, the set value is indicated in the SV Display.

During this time, all outputs and the LED indicators are in OFF status.

Control will then start, indicating the PV in the PV display and SV1 or SV2 in the SV display.

While control output OFF function is working, press the key for approximately 1 second.

### (Table. 5-1)


Companies est	°(	C	ľ	r
Sensor input	PV display	SV display	PV display	SV display
K	ELLE	1370	E F	2500
,	E	4000	E□.F	7500
J	J	1000	JUF	1800
R	- Ε	1750	r F	3200
S	5	1750	5 F	3200
В	ЬΠΕ	1820	ьшя	3300
E	ΕΠΕ	800	EF	1500
Т	Γ	4000	Γ□ .F	7500
N	n Ε	1300	n F	2300
PL-Ⅱ	PL2E	1390	PL2F	2500
C (W/Re5-26)	c	23 15	c F	4200
Pt100	Pr .E	8500	PT .F	9999
JPt100	JPT.E	5000	JPT.F	9000
Pt100	PIUE	850	PIUF	1500
JPt100	JPFE	S00	JPFF	300
4 to 20mA DC	420R			
0 to 20mA DC	020R			
0 to 1V DC	C 18	Cooling bisk	limit value	
0 to 5V DC	058	Scaling high	iiiiii value	
1 to 5V DC	:058			
0 to 10V DC	0 108			



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com





### ADD FURNACE CO.,LTD.


44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170


โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258

https://www.add-furnace.com E-mail: sales@add-furnace.com

EIIC:Κ	-2	00 to 1370°C	E F: K	-320 to 2500 F
<u>ک</u> . ⊡ ځ	-199	.9 to 400.0℃	₽□.E	-199.9 to 750.0 F
J	-2	00 to 1000℃	J F: J	-320 to 1800F
c∐€:R		0 to 1760°C	r F:R	0 to 3200 F
SIII C:S		0 to 1760℃	SUF:S	0 to 3200 T
6		0 to 1820°C	6 F: B	0 to 3300F
EIIC:E		200 to 800℃	E □F: E	-320 to 1500 F
ſ□ .€:T	-199	.9 to 400.0°C	∫ F:T	-199.9 to 750.0°F
oΙΙΣ: N	-2	00 to 1300℃	O F: N	-320 to 2300 F
PL2C: PL-II		0 to 1390℃	PL2F: PL-II	0 to 2500 F
c I C: C(W/Re	5-26)	0 to 2315°C	c DF: C(W/Re	5-26) 0 to 4200°F
PF .C: Pt100			PF .F: Pt100	-199.9 to 999.9T
JP F.C : JPt100	-199	.9 to 500.0°C	JPT,F: JPt100	-199.9 to 900.0°F
P	_	200 to 850℃	PF □ F: Pt100	-300 to 1500°F
JPFE: JPt100		200 to 500℃	JPFF: JPt100	-300 to 900°F
420A: 4 to 20				000 10 000
020R: 0 to 20				
□ 18: 0 to 1V				
0 58:0 to 5V				
1 5 8: 1 to 5V	DC	-1999 to 9	999	
0 108:0 to 10		-1999 to 9		

	Alarm type
	HIII (High limit alarm): The alarm action is the ±deviation setting from the SV. The alarm is activated if the input value reaches the high limit set value.
	L III (Low limit alarm): The alarm action is the ±deviation setting from the SV. The alarm is activated if the input value goes under the low limit set value.
	HL (High/Low limits alarm): Combines High limit and Low limit alarm actions. When input value reaches high limit set value or goes under the low limit set value, the alarm is activated.
	5! d□ (High/Low limit range alarm): When input value is between the high limit set value and low limit set value, the alarm is activated.
	R与□□ (Process high alarm), r R与□ (Process low alarm): Within the scale range of the controller, alarm action points can be set at random and if the input reaches the randomly set action point, the alarm is activated.
4	$H \square \tilde{\omega}$ (High limit alarm with standby), $L \square \tilde{\omega}$ (Low limit alarm with standby),
	HL 🗇 (High/Low limits alarm with standby):
	After the power to the controller is turned on, even if the input enters the alarm action range, the alarm is not activated. If SV is changed while the controller is running, the alarm is not activated even if input is in the alarm action range. (If the controller is allowed to keep running, once the input exceeds the alarm action





# ADD

## บริษัท เอดีดี เฟอร์เนส จำกัด

### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 5.2 Main setting mode

Press the  $\bigcirc$  key in the PV/SV display mode to enter the Main setting mode. The SV can be increased or decreased by pressing the  $\bigcirc$  or  $\bigcirc$  key. If the key is pressed, the SV is registered, and the controller will revert to the PV/SV display mode.

Character	Name, Function, Setting range	Default value						
5	sv	O°C						
	<ul> <li>Sets SV1 (desired value).</li> </ul>							
	Setting range: SV low limit to SV high limit or							
	Scaling low limit value to Scaling high limit value							
5,2[[[]	SV2	O°C						
	<ul> <li>Sets SV2 (desired value).</li> </ul>							
	Not available if Serial communication (option) is added							
	Setting range: SV low limit to SV high limit or							
	Scaling low limit value to Scaling high limit va	llue						

### 5.3 Sub setting mode

Press the key while holding down the key in the PV/SV display mode to enter the Sub setting mode.

The  $\triangle$  or  $\nabla$  key increases or decreases the set value (numeric value).

By pressing the key, the set value is registered, and the unit moves to the next setting item

setting item.		
Character	Name, Function, Setting range	Default value
85	**AT/Auto-reset Perform/Cancel  * Selects AT or Auto-reset (offset correction) Perform/Cance  * Auto-reset can be performed only during PD and P control  * Not available for PI and ON/OFF control.  * Selection item: : AT/Auto-reset Cancel  **RFTTT/F SEF: AT/Auto-reset Cancel  **RFTTT/F SEF: AT/Auto-reset Perform  * Default: AT/Auto-reset Cancel  **[About AT]*  * If the AT Perform is selected, the AT indicator flashes, and the PV/SV display mode.  * After AT is finished, the AT indicator is turned off, and P, I automatically set.  * During AT, none of the settings can be performed.  * If the AT is cancelled during the process, P, I, D and ARW previous value at which AT was performed.  * If the ID key is pressed during AT, control output OFF fur activated, and if the ID key is pressed again, AT is cancel  * AT will be forced to stop if it has not been completed withing the auto-reset (offset correction)  * If the auto-reset is performed, offset correction immediate the controller reverts to the PV/SV display mode.(The correction automatically set and the AT indicator flashes.)  * During 4 minutes of auto-reset performance, other setting performed to prevent key misoperations.  * After auto-reset ends, the AT indicator is turned off, and a be performed.	ol.  d the controller reverts to  J. D and ARW values are  V values revert to the  Inction is  Iled.  in 4 hours.  Ely starts, and ected value is  s cannot be
P	OUT1 proportional band  • Sets OUT1 proportional band.  ON/OFF control when set to 0 or 0.0.  • Setting range: 0 to 1000(0 to 2000)  With a decimal point: 0.0 to 999.9(0.0 to 999.9)  DC input: 0.0 to 100.0%	<b>10°</b> ℃



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Character	Name, Function, Setting range		Default value		
P_6	OUT2 proportional band		1.0 times		
	Sets OUT2 proportional band.				
	ON/OFF control (OUT2) when set to 0 or 0.0.				
	Not available if Heating/Cooling control (option) is not added or if OUT1				
	is in ON/OFF control	otom to OUT4 man	- uti - u     u  \		
	Setting range: 0.0 to 10.0 times (multiplying factors)	ctor to OOTT prope			
1 [ ] [ ]	Integral time • Sets the integral time.		200 seconds		
	Setting the value to 0 disables the function (PD	control)			
	Not available if OUT1 is in ON/OFF control	control).			
	Setting range: 0 to 1000 seconds				
d	Derivative time		50 seconds		
<b>~</b> :ii	Sets the derivative time.		00 00001100		
	Setting the value to 0 disables the function (PI of	ontrol).			
	Not available if OUT1 is in ON/OFF action	,			
	Setting range: 0 to 300 seconds				
П	ARW (Anti-reset windup)		50%		
* *	Sets the ARW (anti-reset windup).				
	Available only for PID control				
	Setting range: 0 to 100%				
<b>_</b>	OUT1 proportional cycle	30 sec: Relay co			
	• Sets OUT1 proportional cycle.		tact voltage output		
	Not available for ON/OFF control or DC current		!-		
	•For the relay contact output type, if the prop				
	decreased, the frequency of the relay action of the relay contact is shortened.	increases, and th	ie ilie		
	Setting range: 1 to 120 seconds				
c _ b 🗆	OUT2 proportional cycle	30 sec: Relay co	ontact output		
L _ U	Sets OUT2 proportional cycle.		act voltage output		
	<ul> <li>Not available for ON/OFF control or DC current</li> </ul>				
	Not available if Heating/Cooling control (option) is not added or if OUT2				
	is in ON/OFF control				
	•For the relay contact output type, if the proportional cycle time is				
	decreased, the frequency of the relay action inc	reases, and the life	e		
	of the relay contact is shortened.				
<b>5</b>	Setting range: 1 to 120 seconds		200		
$R : \square$	A1 value		<b>0</b> °C		
	• Sets the action point of A1 output.	-4!			
	Setting the value to 0 or 0.0 disables the fund				
	<ul> <li>(Excluding Process high alarm and Process</li> <li>Not available if No alarm action is selected dur</li> </ul>		loction		
	Setting range: Refer to (Table 5.3-1).	ing the AT type se	IECTION		
	A2 value		<b>0</b> °C		
R2::::	Sets the action point of A2 output.		<u> </u>		
	Setting the value to 0 or 0.0 disables the fund	ction			
	(Excluding Process high alarm and Process				
	Not available if A2 output (option) is not added	-	on is		
	selected during the A2 type selection				
	• Setting range: Refer to (Table 5.3-1).				
	J = J = = = = ( = = = = = = = = = = = =				



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Character	Name, Function, Setting range	Default value
and X.X, alternating display	<ul> <li>Heater burnout alarm value</li> <li>Sets the heater current value for Heater burnout alarm.</li> <li>Setting the value to 0.0 disables the function.</li> <li>CT current value and character</li></ul>	set value) in
LP_F	Loop break alarm time  Sets the action time to assess the Loop break alarm.  Available only when Loop break alarm (LA option) is added. Setting range: 0 to 200 minutes	0 minutes
LP_H	Loop break alarm span  • Sets the action span to assess the Loop break alarm.  • Available only when Loop break alarm (LA option) is added  • Setting range: 0 to 150°C(°F), however,  with a decimal point: 0.0 to 150.0°C(°F)  DC input: 0 to 1500 (The placement of the decimal points)	<b>0</b> °C point

## [A1, A2 setting range] (Table 5.3-1)

(Table 616-1)	
Alarm type	Setting range
High limit alarm	-Input span to Input span°C(°F)*1
Low limit alarm	-Input span to Input span°C (°F)*1
High/Low limits alarm	0 to Input span°C (°F)*1
High/Low limit range alarm	0 to Input span°C (°F)*1
Process high alarm	Input range low limit to Input range high limit *2
Process low alarm	Input range low limit to Input range high limit *2
High limit alarm with standby	-Input span to Input span°C (°F)*1
Low limit alarm with standby	-Input span to Input span°C (°F)*1
High/Low limits alarm with standby	0 to Input span°C (°F)*1

<sup>•</sup> When the input has a decimal point, the negative low limit value is –199.9, and the positive high limit value is 999.9.

### [Loop break alarm]

The alarm will be activated when the PV does not **rise** as much as the span or more within the time it takes to assess the loop break alarm after the MV has reached 100% or the output high limit value.

The alarm will also be activated when the PV does not **fall** as much value as the span or more within the time it takes to assess loop break alarm after the MV has reached 0% or the output low limit value.

When the control action is Direct (Cooling), read "fall" for "rise" and vice versa.

<sup>\*1:</sup> For DC input, the input span is the same as the scaling span.

<sup>\*2:</sup> For DC input, input range low (or high) limit is the same as the scaling low (or high) limit.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ช 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 5.4 Auxiliary function setting mode 1

Press the key for approx. 3 seconds while holding down the key in the PV/SV display mode. The unit enters Auxiliary function setting mode 1.

The set values can be increased or decreased by pressing the or key.

If the Q key is pressed, the set value is registered, and the unit moves to the next setting item

	y is pressed, the set value is registered, and the unit moves to the ne	
Character	Name, Function, Setting range	Default value
Foce	<ul> <li>Set value lock</li> <li>Locks the set values to prevent setting errors.</li> <li>The setting item to be locked depends on the selection.</li> <li>When selecting Lock, set the necessary items in the Unlock status, then select Lock 1, Lock 2 or Lock 3.</li> <li>Selection item:  <ul> <li>(Unlock): All set values can be changed.</li> <li>(Lock 1): None of the set values can be changed.</li> <li>(Lock 2): Only SV can be changed.</li> <li>(Lock 3): All set values except input type can be changed.</li> <li>However, they reverts to their previous value after the power is turned off because they are not saved in the non-volatil representation of the set value of the set value of the set value of the setting, the value will not be written in the non-volatile mem Do not change any setting item in Auxiliary function setting mode 2.</li> </ul> </li> </ul>	memory. the e nory.) etting 2 is
5 <i>H</i>	<ul> <li>and Alarm value.</li> <li>SV high limit</li> <li>Sets SV high limit.</li> <li>Setting range: SV low limit to input range high limit value</li> <li>DC input: SV low limit to scaling high limit value</li> <li>(The placement of the decimal point follows the selection.)</li> </ul>	1370°C
4 <u>[</u> ]	SV low limit  Sets SV low limit.  Setting range: Input range low limit value to SV high limit value  DC input: Scaling low limit value to SV high limit value  (The placement of the decimal point follows the selection.	-200°C
50	Sensor correction  • Sets the sensor correction value.  This corrects the input value from the sensor. When a sensor cannot be set at the exact location where control is desired, temperatures measured by the sensor may deviate from the temperature in the controlled location. When controlling with plural controllers, sometimes the measured temperatures (input value) do not concur due to differences in sensor accuracy or dispersion of load capacities. In such a case, the control can be set at the desired temperature (SV) by adjusting the input value of sensors. However, it is effective within the input rated range regardless of the sensor correction value.  PV after sensor correction= Current PV+ (Sensor correction value)  • Setting range: -100.0 to 100.0()DC input: -1000 to 1000 (The placement Point follows)	nt of the decimal the selection.)



### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ช 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <a href="mailto:sales@add-furnace.com">sales@add-furnace.com</a>

Character	Name, Function, Setting range	Default value
cñhL	Communication protocol  • Selects communication protocol.  • Available only when the Serial communication (option) is added  • Selection item: root (Shinko protocol)  rood (Modbus ASCII)  rood (Modbus RTU)	Shinko protocol
cñno	<ul> <li>Instrument number</li> <li>Sets the instrument number. (The instrument number should be set individually when communicating by connecting plural instruments in Serial communication. Otherwise it is impossible to communicate.)</li> <li>Available only when the Serial communication (option) is added</li> <li>Setting range: 0 to 95</li> </ul>	0
спър	Communication speed  • Selects the communication speed.  (The communication speed of the controller must be equal to that of host computer. Otherwise communication is impossible.)  • Available only when the Serial communication (option) is added  • Selection item: ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	9600bps
cñPr	Parity  • Selects the parity.  • Not available if the Serial communication (option) is not added or if Shinko protocol is selected during the Communication protocol selection.  • Selection item: COCE (No parity), EBER (Even parity)	Even parity
cñhſ	<ul> <li>Stop bit</li> <li>Selects the stop bit.</li> <li>Not available if the Serial communication (option) is not added or if Shinko protocol is selected during the Communication protocol selection mode.</li> <li>Selection item:  (Stop bit 1), (Stop bit 2)</li> </ul>	1

5.5 Auxiliary function setting	mada 2

	key for approx. 3 seconds while holding down the	key in the PV/SV
display mode.	The unit enters Auxiliary function setting mode 2.	

The set values can be increased or decreased by pressing the  $\nabla$  or key. If the  $\bigcirc$  key is pressed, the set value is registered, and the unit moves to the next setting item.

If Lock 3 is selected in the Set value lock selection, release Lock 3 to Unlock,

then change each set value in Auxiliary function setting mode 2.

Character	Name, Function, Setting range	Default value
5E05	Input type	K (-200 to 1370)
	<ul> <li>An input type from thermocouple (10 types), RTD (2 types), DC</li> </ul>	
	current (2 types), DC voltage (4 types) and the unit/can be selected.	
	•When changing the input from DC voltage to other inputs,	
	remove the sensor connected to this controller, then change	
	the input. If the input is changed with the sensor connected, the	
	input circuit may break.	



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

			Input range						
EIIIE	-200	to	<b>1370</b> °C	EIF	-320	to	<b>2500</b> °C		
⊱∷ ∴	-199.9	to	400.0 °C	E□ .F	-199.9	to	<b>750.0</b> °C		
JIIE	-200	to	1000 °C	J	-320	to	1800 °C		
- <u>-                                  </u>	0	to	<b>1760</b> °C	r	0	to	<b>3200</b> °C		
500E	0	to	<b>1760</b> °C	4 F	0	to	<b>3200</b> °C		
₽IIIE	0	to	<b>1820</b> °C	b⊞F	0	to	<b>3300</b> °C		
	-200	to	800 °C	EUF	-320	to	<b>1500</b> °C		
Γ□ .Ε	-199.9	to	400.0 °C	Γ□ .F	-199.9	to	<b>750.0</b> °C		
$\cap \square \mathcal{L}$	-200	to	1300 °C	∩∭F	-320	to	<b>2300</b> °C		
PF .C	0	to	1390 °C	PL 2F	0	to	<b>2500</b> °C		
c	0	to	<b>2315</b> °C	c TF	0	to	<b>4200</b> °C		
PF .C	-199.9	to	<b>850.0</b> °C	Pr F	-199.9	to	999.9 °C		
JPT.E	-199.9	to	<b>500.0</b> °C	JPT.F	-199.9	to	900.0 °C		
PFOE	-200	to	<b>850</b> °C	PIUF	-300	to	<b>1500</b> °C		
JPFE	-200	to	<b>500</b> °C	JPFF	-300	to	900 °C		
420R	–1999 to	9999		<u> </u>					
020R	–1999 to	9999							
00 18									
/□58									
		9999							
							9999		
Scaling lov		cemen	t of the decimal	point follows the	Selection.)		<b>–1999</b>		
		/alue					-1999		
			ut						
				scaling high limit	value(The	olace	ement of the decimal		
point follows	the selection	n.)							
							No decimal point		
• Selects the	e decimal po	oint pla	ice.				·		
<ul> <li>Selection i</li> </ul>									
		,							
		,							
DV 4:14 = 4!		(3	uigits after the	uecimai point)			0.0000000		
		etant					0.0 seconds		
			o large it affect						
the delay of		, 501 10	o largo, it alroot	s control result d	uo to				
	E	Company   Comp	Land Care   Land	E	ECC -200 to 1370°C EFF  ECC -199.9 to 400.0°C EFF  JUC -200 to 1000°C JUCF  CO to 1760°C C CFF  SUC 0 to 1820°C SUCF  ECC 0 to 1820°C SUCF  ECC -200 to 800°C EFF  CO TO 1390°C C FEF  PL C -199.9 to 400.0°C C FEF  PL C -200 to 1300°C C FEF  PL C -199.9 to 3990°C C FEF  PL C -199.9 to 5500.0°C PF F  JPFC -200 to 850°C PF F  JPFC -200 to 500°C JPFF  PL C -200 to 500°C JPFF  SUC -200 to 500°	C	C		



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Character	Name, Function, Setting range	Default value
oLH□	OUT1 high limit	100%
OCT	Sets the OUT1 high limit value.	
	Not available for ON/OFF control	
	Setting range: OUT1 low limit value to 100% (Relay contact output)	
	Non-contact voltage output	)
	OUT1 low limit value to 105% (DC current output)	
oLL	OUT1 low limit	0%
	• Sets OUT1 low limit value.	
	Not available for ON/OFF control	
	• Setting range: 0% to OUT1 high limit value (Relay contact output,	
	Non-contact voltage of	utput)
11111	-5% to OUT1 high limit value (DC current output)	1.0
HY5	OUT1 ON/OFF hysteresis  • Sets ON/OFF hysteresis for OUT1.	1.0
	Available for ON/OFF control	
	• Setting range: 0.1 to 100.0()	
	DC input: 1 to 1000 (The placement of the decimal p	ooint
	follows the selection.)	John
cRcF	OUT2 action mode	Air cooling
22.	<ul> <li>Selects OUT2 cooling action from air cooling, oil cooling and water</li> </ul>	•
	cooling.	
	Not available if Heating/Cooling control (option) is not added or if OL	JT2is in
	ON/OFF control.	
	Selection item:	
	R! - (Air cooling, linear characteristic)	
	(Oil cooling, 1.5th power of the linear characteristic)	
	United Section (Water cooling, 2nd power of the linear characteristic)	
оLЖЬ	OUT2 high limit	100%
	• Sets the high limit value for OUT2.	VITO
	<ul> <li>Not available if Heating/Cooling control (option) is not added or if C</li> </ul>	0012
	is in ON/OFF control.  • Setting range: OUT2 low limit value to 100% (Relay contact output)	
	Non-contact voltage output)	,
	OUT2 low limit value to 105% (DC current output)	
0116	OUT2 low limit	0%
0110	• Sets the low limit value for OUT2.	076
	<ul> <li>Not available if Heating/Cooling control (option) is not added or if C</li> </ul>	II IT2is in
	ON/OFF control.	0 1213 111
	• Setting range: 0% to OUT2 high limit value (Relay contact output,	
	Non-contact voltage of	utput)
	-5% to OUT2 high limit value (DC current output)	- 1 - 7
db⊞	Overlap band/Dead band	<b>0.0</b> °C
00:	<ul> <li>Sets Overlap band/Dead band for OUT1 and OUT2.</li> </ul>	
	+ set value: Dead band, -set value: Overlap band	
	<ul> <li>Not available if Heating/Cooling control (option) is not added.</li> </ul>	
	• Setting range: -100.0 to 100.0°C(°F)	
	DC input: -1000 to 1000 (The placement of the decin	nal
	point follows the selection.	
	Familiana ara seneral,	,



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Character	Name, Function, Setting range	Default value			
HY56	OUT2 ON/OFF hysteresis		<b>1.0</b> °C		
	Sets ON/OFF hysteresis for OUT2.				
	<ul> <li>Available when Heating/Cooling c</li> </ul>	control (option) is added and w	henOUT2 is in		
	ON/OFF control.				
	<ul> <li>Setting range: 0.1 to 100.0(), DC i</li> </ul>	input: 1 to 1000 (The placeme	nt of the decimal		
	point follows the selection.)	T.,			
RL IF	A1 type		o alarm action		
	Selects Alarm 1 type.[Note] When  Towards to the default value 0 (0.0)	i an aiarm type is changed, th	e alarm value		
	reverts to the default value 0 (0.0).  • Selection item:				
	: No alarm action	৪১ : Process high ala	arm		
	HIII:: High limit alarm	- 유수 : Process low alar			
	Luu: Low limit alarm	H□□ : High limit alarm			
	HL : High/Low limits alarm	: Low limit alarm			
	ūl d□ : Hi/Lo limit range alarm	HL : High/Low limits	•		
RL2F	A2 type		No alarm action		
	<ul> <li>Selects Alarm 2 type.[Note] When</li> </ul>	n an alarm type is changed, the	e alarm value		
	reverts to the default value 0 (0.0).				
	<ul> <li>Available only when A2 option is a</li> </ul>				
	<ul> <li>Selection items are the same as t</li> </ul>				
A ILĀ	A1 action Energized/De-energize		Energized		
	<ul> <li>Selects A1 action Energized/De-energized.</li> <li>Not available if No alarm action is selected during the A1 type selection.</li> </ul>				
			election.		
	• Selection item nonL (Energized)	•			
82LA	「とどう (De-energiz A2 action Energized/De-energize	,	Energized		
11,5,5,11	• Selects Energized or De-energized for A2 action.				
	<ul> <li>Not available if No alarm action is</li> </ul>		election		
	or if A2 (option) is not added.	3, p = 3, p = 3			
	<ul> <li>Selection items are the same as the</li> </ul>	hose of A1 action Energized/			
	De-energized selection.	<u> </u>			
8 189	A1 hysteresis		<b>1.0</b> °C		
	<ul> <li>Sets A1 hysteresis.</li> </ul>				
	Not available if No alarm action is selected during the A1 type selection				
	• Setting range: 0.1 to 100.0°C(°F),				
	DC input: 1 to 1000	(The placement of the decim	al point		
		follows the selection			
85HA	A2 hysteresis		<b>1.0</b> °C		
	Sets A2 hysteresis.				
	Not available if No alarm action is	selected during the A2 type s	election		
	or if A2 (option) is not added.				
	Setting range is the same as those of A1 hysteresis setting.				

## ADD

## บริษัท เอดีดี เฟอร์เนส จำกัด

### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

Character	Name, Function, Setting range	Default value
8 183	A1 action delay timer	0 seconds
	<ul> <li>Sets A1 action delay timer. When setting time has elapsed after the input enters the alarm outpurange, the alarm is activated.</li> <li>Not available if No alarm action is selected during the A1 type select</li> <li>Setting range: 0 to 9999 seconds</li> </ul>	
8289	A2 action delay timer	0 seconds
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	<ul> <li>Sets A2 action delay timer. When setting time has elapsed after the input enters the alarm outpur range, the alarm is activated.</li> <li>Not available if No alarm action is selected during the A2 type select or if A2 option is not added.</li> <li>Setting range: 0 to 9999 seconds</li> </ul>	t
conf	Direct/Reverse actionReverse• Selects Reverse (Heating) or Direct (Cooling) control action.• Selection item:[Reverse (Heating), [Direct (Cooling))	e (Heating) action ing)]
Ar_b	<ul> <li>AT bias</li> <li>Sets the bias value when AT is performing.</li> <li>Not available for the DC input</li> <li>Setting range: 0 to 50°C(0 to 100°F)</li> <li>With a decimal point: 0.0 to 50.0°C(0.0 to 100.0°F)</li> </ul>	<b>20</b> °€
58 <sub>-</sub> 6	<ul> <li>SVTC bias</li> <li>The SV adds SVTC bias value to the value received by the SVTC command (Set value digital transmission).</li> <li>Available only when the Serial communication (option) is added.</li> <li>Setting range: Converted value of20% of the rated value.  DC input: Converted value of20% of the scaling span (The placement of the decimal point follows the selection.)  However, the negative minimum value is -1999, -199.9, -19.9or -1.999.</li> </ul>	
<i>५8</i> □2	<ul> <li>SV2 indication</li> <li>Selects either Indication or No indication of SV2.</li> <li>Not available if Serial communication (option) is added.</li> <li>Selection item:  (Indication),  FF (No indication)</li> </ul>	Indication
EaUF		veen
ล์หิลป	OUT/OFF Key function  • Selects whether the OUT/OFF Key (①) is used for "Control output of for "Auto/Manual control function".  • Selection item: □FF□ (Control output OFF function), GRoU (Auto/Manual control function)	ut OFF function OFF function" or



### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>


### [Energized/De-energized]


When alarm action Energized is selected, the alarm output (between terminals 7-8, or 12-13) is conducted (ON) while the alarm output indicator is lit.

The alarm output is not conducted (OFF) while the alarm output indicator is not lit. See (Fig. 5.5-1).

When alarm action De-energized is selected, the alarm output (between terminals 7-8, or 12-13) is not conducted (OFF) while the alarm output indicator is lit.

The alarm output is conducted (ON) while the alarm output indicator is not lit. See (Fig. 5.5-2).





High limit alarm (when Energized is set) (Fig. 5.5-1)

High limit alarm (when De-energized is set) (Fig. 5.5-2)

### 5.6 Control output OFF function

- A function to pause the control action or turn the control output of the unused instrument of the plural units OFF even if the power to the instrument is supplied.
- Pressing the key (OUT/OFF Key) for approx. 1 sec from any mode turns the control output OFF.

[ • FF ] is indicated in the PV display while this function is working.

In this status, pressing the key again for approx. 1 second cancels this function.

• Once the Control output OFF function is enabled, the function cannot be released even if the power to the instrument is turned OFF and ON again.

To cancel this function, prest the key again for approx. 1 second.

### 5.7 Auto/Manual control switching function

- Select "Auto/Manual control function" during the "OUT/OFF Key function" selection in Auxiliary function setting mode 2.
- Press the () key in the PV/SV display mode. Auto/Manual control can be switched.
- If the control action is changed from automatic to manual control, the MV on the SV display flashes. The control can be performed manually by increasing or decreasing the MV in the SV Display with the  $\triangle$  or  $\nabla$  key.
- By pressing the ① key again, the unit reverts to the PV/SV display (automatic control) mode.

When the power supply to the instrument is turned ON, automatic control starts.

- When control is changed from automatic to manual and vice versa, the balanceless-bumpless function works to prevent sudden change of the MV.
- If Auto/Manual control function is selected, Control output OFF function is disabled.

### 5.8 MV indication

- If the key is pressed for approx. 3 seconds in the PV/SV display mode, the MV will be indicated in the SV Display. During the MV indication, the last point on the right in the SV Display flashes at a cycle of 500ms.
- By pressing the key again, the unit reverts to the PV/SV display mode.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

## 6. Operation

After the unit is mounted to the control panel and wiring is completed, operate the unit following the procedures below.

### (1) Turn the power supply to the JCR-33A, JCD-33A ON.

**Thermocouple and RTD inputs:** Sensor input characters and temperature unit are indicated in the PV Display, and the input range high limit value is indicated in the SV Display for approx. 3 seconds after the power is switched ON. See (Table 6-1).

**DC input:** Sensor input characters are indicated in the PV Display, and the scaling high limit value is indicated in the SV Display for approx. 3 seconds after the power is switched ON. See (Table 6-1).

However, if the scaling high limit value has been changed during the Scaling high limit setting, the changed value is indicated in the SV Display.

During this time, all outputs and the LED indicators are in OFF status.

After that, control starts, indicating the PV in the PV Display, and SV1 or SV2 in the SV Display. When the Control output OFF function is working, [ FF ] is indicated in the PV Display. To cancel this function, press the key again for approx. 1 second.

(Table 6-1)

Input type		°C		°F	
	PV display	SV display	PV display	SV display	
K	E	1370	EUDF	2500	
	E□ .E	4000	Ŀ□ .F	7500	
J	JIIIE	1000	JIIF	1800	
R	- III	1760	r III F	3200	
S	5 <u>□</u>	1760	5F	3200	
В	ЬШС	1820	ЬШЕ	3300	
E	ΕΠΙΣ	800	EIIF	<i>1500</i>	
T	Γ	4000	Γ□ .F	7500	
N	$\cap \coprod \mathcal{L}$	1300	$\cap \coprod F$	2300	
PL- II	PL 20	1390	PL2F	2500	
C (W/Re5-26)		23 15	c IIIF	4200	
Pt100	PF E	85QO	PT F	9999	
JPt100	JPF.E	5000	JPT.F	9000	
Pt100	$P \Gamma \square \Gamma$	□85 <i>0</i>	$P \Gamma \Box F$	1500	
JPt100	JPFE	_5 <i>00</i>	JPFF	<b>300</b>	
4 to 20mA DC	420A				
0 to 20mA DC	020A				
0 to 1V DC	80 IB	Scaling high	limit valuo		
0 to 5V DC	<i>0</i> _58	Scaling high	iiiiii valu <del>e</del>		
1 to 5V DC	<i>i</i> ∐5 <i>8</i>				
0 to 10V DC	0 108				

### (2) Input each set value.

Input each set value, referring to "5. Setup".

### (3) Turn the load circuit power ON.

Control action starts so as to keep the control target at the SV.




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com


## 7. Action explanation

### 7.1 OUT1 action



: Turns ON (lit) or OFF (unlit).

### 7.2 Heater burnout alarm action (option)



When the Heating/Cooling control (option) is added, terminals 12 and 13 are used for the Heater burnout alarm.



### ADD FURNACE CO.,LTD.

44 ชอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 7.3 OUT1 ON/OFF control action

	Heating (reverse) action		Cooling (direct) action			
	ON —	Hysteresis			Hysteresis	ON
Control action	OFF-	, , , , , , , , , , , , , , , , , , ,	<u>,                                     </u>		V	OFF
R/_	H4   C5   C6   C6   C6   C6   C6   C6   C6		нФ— с <del>б—</del> L 6—	нФ- сб- г6-		нФ¬  сб→ф ∟б→
S/□	+ ⑤ ☐ 12V DC - ⑥ ☐		+5 0V DC -6	+5¬ 0V DC -6¬		+5¬ 12V DC -6¬
A/□	+ ⑤ — 20mA DC - ⑥ —		+5 4mA DC -6	+ ⑤		+ ⑤ ¬ 20mA DC - ⑥ ¬
Indicator (OUT1) Green	Lit		Unlit	Unlit		Lit

: Turns ON (lit) or OFF (unlit).




### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 7.4 OUT2 (Heating/Cooling control) action (option)



: Turns ON (lit) or OFF (unlit).

: Represents Heating control action.

--- : Represents Cooling control action.




### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### When setting Dead band



: Turns ON (lit) or OFF (unlit).

\_\_\_\_\_: Represents Heating control action.

\_\_\_ : Represents Cooling control action.




### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### When setting Overlap band with Relay contact output



: Turns ON (lit) or OFF (unlit).

\_\_\_\_\_: Represents Heating control action.

\_ \_ \_ : Represents Cooling control action.




### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

7.5 A1 and A2 action



For A2 output, use terminals 12 and 13.

A1 and A2 indicators light when their output terminals are closed, and go off when their output terminals are opened.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 7.6 SV1/SV2 external selection

	SV1	SV2
SV1/SV2 external selection	∰_;  Ɗ_;	<b>(4)</b>
Indicator Green	SV1 SV2 Lit Unlit	SV1 SV2 Unlit Lit

### If the Serial communication option is added, this function is disabled.

SV1 or SV2 can be selected by the external operation.

Between terminals 14 and 17 Open: SV1 can be selected.

Between terminals 14 and 17 Closed: SV2 can be selected.

SV1 or SV2 cannot be selected by the external operation during setting mode or AT

## 8. Control action explanations

### 8.1 PID

### (1) Proportional band (P)

Proportional action is the action during which the control output varies in proportion to the deviation between the SV and the PV.

If the proportional band is narrowed, even if the output changes by a slight variation of the PV, better control results can be obtained as the offset decreases.

However, if the proportional band is narrowed too much, even slight disturbances may cause variation in the PV, control action changes to ON/OFF control and the so-called hunting phenomenon occurs.

Therefore, when the PV comes to the balanced position near the SV and a constant temperature is maintained, the most suitable value is selected by gradually narrowing the proportional band while observing the control results.

### (2) Integral time (I)

Integral action is used to eliminate offset. When the integral time is shortened, there turning speed to the set point is accelerated. However, the cycle of oscillation is also accelerated and stability becomes unfavorable.

### (3) Derivative time (D)

Derivative action is used to restore the change in the PV according to the rate-of-change. It reduces the amplitude of overshoot and undershoot width. If the derivative time is shortened, restoring value becomes small, and if the derivative time is adjusted to be longer, an excessive returning phenomenon may occur and the control system may oscillate.



### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

### 8.2 AT of this controller


In order to set each value of P, I, D and ARW automatically, the AT process should be made to fluctuate to obtain an optimal value.

For DC input, the AT process will fluctuate around the SV for conditions of (A), (B) and(C) below.

Sometimes the AT process will not fluctuate if AT is performed at or near room temperature. Therefore AT might not finish normally.

(A) In the case of large difference between the SV and PV as the temperature is rising.

When AT bias is set to 20°C, the AT process will fluctuate at a temperature 20°C lowerthan the SV.




- (1) Calculating PID constant
- (2) PID constant calculated
- (3) Controlled by the PID constant set by AT.
- (4) AT bias value

(Fig. 8.2-1)

(B) When the control is stable or when PV is within  $\pm 20^{\circ}\mathrm{C}$  of the SV.


The AT process will fluctuate around the SV.



- (1) Calculating PID constant
- (2) PID constant calculated
- (3) Controlled by the PID constant set by AT.

(Fig. 8.2.2)

(C) In the case of a large difference between the SV and PV as the temperature is falling When AT bias is set to  $20^{\circ}$ C, the AT process will fluctuate at a temperature  $20^{\circ}$ C higher than the SV.



- (1) Calculating PID constant
- (2) PID constant calculated
- (3) Controlled by the PID constant set by AT.
- (4) AT bias value

(Fig. 8.2-3)



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170


โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

### 8.3 Auto-reset (offset correction)

Auto-reset is performed to correct the offset at the point at which PV indication is stabilized within the proportional band during the PD control.

Since the corrected value is internally memorized, it is not necessary to perform the auto-reset again as long as the process is the same.

However, when the proportional band (P) is set to 0, the corrected value is cleared.



## 9. Specifications

9.1 Standard specifications Mounting : Flush

Setting : Membrane sheet key

Display

JCR-33A PV display: Red LED 4 digits, character size, 11.2 x 5.4 (H x W)mm

SV display: Green LED 4 digits, character size, 11.2 x 5.4 (H x W)mm JCD-33A PV display: Red LED 4 digits, character size, 18 x 8 (H x W)mm

SV display: Green LED 4 digits, character size, 12.6 x 6(H x W)mm

**Accuracy (Setting, indication)** 

Thermocouple: Within  $\pm 0.2\%$  of each input span  $\pm 1$  digit or within  $\pm 2^{\circ}$ C(4°F),

whichever is greater

However, R, S inputs, 0 to  $200^{\circ}$ C(0 to  $400^{\circ}$ F): Within  $\pm 6^{\circ}$ C( $12^{\circ}$ F) B input, 0 to 300°C(0 to 600°F): Accuracy is not guaranteed. K, J, E, T, N inputs, less than 0(32): Within 0.4% of each

input span1digit

**RTD** : Within  $\pm 0.1\%$  of each input span  $\pm 1$  digit or within  $\pm 1^{\circ}$ C( $2^{\circ}$ F),

whichever is greater

DC Voltage and Current:

Within  $\pm 0.2\%$  of each input span  $\pm 1$  digit

Input sampling period: 250ms

Input

Thermocouple: K, J, R, S, B, E, T, N, PL-II, C (W/Re5-26)

External resistance: 100Ωor less,

however, for B, 40Ωor less

RTD: Pt100, JPt100, 3-wire system

Allowable input lead wire resistance: 10Ωor less per wire

DC current: 0 to 20mA DC, 4 to 20mA DC

Input impedance:  $50\Omega$ 

[50Ωshunt resistor (sold separately) must be connected

between input terminals.]

Allowable input current: 50mA or less

[When  $50\Omega$ shunt resistor (sold separately) is used]



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

DC voltage: 0 to 1V DC:

Input impedance:  $1M\Omega$ or more Allowable input voltage: 5V or less

Allowable signal source resistance: 2kΩor less

0 to 5V DC, 1 to 5V DC, 0 to 10V DC: Input impedance: 100kΩor more Allowable input voltage: 15V or less

Allowable signal source resistance: 100Ωor less

Input type	Input r	ange	Resolution
К	–200 to 1370 °C	−320 to 2500 °F	1℃(℉)
IX.	–199.9 to 400.0°C		
J	–200 to 1000 °C   –320 to 1800 °F		1℃(℉)
R	0 to 1760 ℃	0 to 3200 °F	1℃(℉)
S	0 to 1760 ℃	0 to 3200 °F	1℃(℉)
В	0 to 1820 ℃	0 to 3300 °F	1℃(℉)
E	–200 to 800 °ℂ	−320 to 1500 °F	1℃(℉)
T	–199.9 to 400.0°C	–199.9 to 750.0°F	0.1℃(℉)
N	–200 to 1300°C	−320 to 2300 °F	1°C(°F)
PL-Ⅱ	0 to 1390 °C		1℃(℉)
C(W/Re5-26)	0 to 2315 ℃ 0 to 4200 ℉		\ /
Pt100	–199.9 to 850.0℃   –199.9 to 999.9℉		0.1℃(℉)
JPt100	–199.9 to 500.0℃   –199.9 to 900.0℉		0.1℃(℉)
Pt100	–200 to 850 °C         –300 to 1500 °F		1℃(℉)
JPt100	–200 to 500 °C	−300 to 900 °F	1℃(℉)
4 to 20mA DC	-1999 to	1	
0 to 20mA DC	-1999 10	'	
0 to 1V DC			
0 to 5V DC	_1000 to	1	
1 to 5V DC	-1999 to 9999 *1 1		
0 to 10V DC			

<sup>\*1:</sup> For DC input, input range and decimal point place are changeable.

\*2: 50shunt resistor (sold separately) must be connected between input terminals.

### **Control output (OUT1)**

Relay contact: 1a1b

Control capacity: 3A 250V AC (resistive load)

1A 250V AC (inductive load cosØ=0.4)

Electrical life: 100,000 cycles

Non-contact voltage: 12+20V DC, maximum 40mA (short circuit protected)

Number of connectable units in parallel when using Shinko SSR:

SA-400 series: 5 units SA-500 series: 2 units

DC current : 4 to 20mA DC

Load resistance, maximum 550

### A1 output

When A1 action is set as energized, the alarm action point is set by the

 $\pm$ deviation from the SV (except Process alarm).

When the input is out of the range, the output turns ON or OFF (in the case of High/Low limit range alarm).

When the alarm action is set as De-energized, the output acts conversely.

Setting accuracy: The same as the Indicating accuracy

Action : ON/OFF action

Hysteresis : Thermocouple, RTD input: 0.1 to 100.0° C(°F)

DC current, voltage input: 1 to 1000

(The placement of the decimal point follows the selection.)

38

## A

### บริษัท เอดีดี เฟอร์เนส จำกัด

### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Output : Relay contact, 1a

Control capacity: 3A 250V AC (resistive load)

Electrical life: 100,000 cycles

### **Control action**

• PID control (with AT function)• PI control: When derivative time is set to 0

• PD control (with auto-reset function): When integral time is set to 0

• P control (with auto-reset function): When integral and derivative times are set to 0

• ON/OFF control: When OUT1 proportional band is set to 0

OUT1 proportional band (P): Thermocouple: 0 to 1000°C(0 to 2000°F)

RTD: 0.0 to 999.9°C(0.0 to 999.9°F) DC current, voltage: 0.0 to 100.0%

[ON/OFF control when set to 0°C(°F), 0.0°C(°F) or 0.0%]

Integral time (I) : 0 to 1000 sec (off when set to 0)
Derivative time (D) : 0 to 300 sec (off when set to 0)

OUT1 proportional cycle: 1 to 120 sec (Not available for DC current output type)

ARW : 0 to 100%

OUT1 ON/OFF hysteresis: Thermocouple, RTD input: 0.1 to 100.0°C(°F)

DC current, voltage input: 1 to 1000 (The placement

of the decimal point follows the selection.)

SV1/SV2 external selection: SV1 and SV2 can be selected by external contact.

Contact OPEN between terminals 14 and 17 : SV1 Contact CLOSED between terminals 14 and 17 : SV2

Contact current: 6mA

Supply voltage: 100 to 240V AC 50/60Hz, 24V AC/DC 50/60Hz


Allowable voltage fluctuation range:

100 to 240V AC : 85 to 264V AC 24V AC/DC : 20 to 28V AC/DC

Ambient temperature: 0 to 50(32 to 122)

**Ambient humidity**: 35 to 85%RH (non-condensing)

**Power consumption**: Approx. 8VA Circuit Insulation configuration



• When OUT1 is non-contact voltage or DC current output type and OUT2 is Non-contact voltage or DC current output type, A is not electrically insulated from B.

When OUT1 is non-contact voltage or DC current output type,
 A is not electrically insulated from C, and A is not electrically insulated from D.
 When OUT2 is non-contact voltage or DC current output type,

B is not electrically insulated from C, and B is not electrically insulated from D.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

### Insulation resistance

 $10M\Omega$  or more, at 500V DC for other combinations except the above mentioned

### Dielectric strength

Between input terminal and ground terminal, 1.5kV AC for 1 minute
Between input terminal and power terminal, 1.5kV AC for 1 minute
Between output terminal and ground terminal, 1.5kV AC for 1 minute
Between output terminal and power terminal, 1.5kV AC for 1 minute
Between power terminal and ground terminal, 1.5kV AC for 1 minute
Weight : JCR-33A (approx. 250g), JCD-33A, (approx. 370g)

**External dimensions**: JCR-33A: 48 x 96 x 110mm (W x H x D)

JCD-33A : 96 x 96 x 110mm (W x H x D)

Material : Case: Flame-resistant resin

**Color** : Case: Light gray **Drip-proof/Dust-proof** : IP66 for the front face

Attached functions :[Sensor correction function], [Set value lock function]

[Input error indication]

linput erro	r indication]				
Output status	Contents and	Output status			
when input	Indication	Ol	JT1		OUT2
abnormal		Direct	Reverse	Direct	Reverse
(*1)		action	action	action	action
on	Overscale	ON (20mA)			ON(20mA)
O.,	Measured value	Or OUT1			or OUT2
	has exceeded	High limit	OFF(4mA)	OFF(4mA)	High limit
	Indication range	value(*2)	orOUT1 low	orOUT2 low	value(*2)
of F	high limit value.	OFF (4mA)or	limit value	limit value	OFF(4mA)or
<i>O' '</i> '	" " flashes.	OUT1 low			OUT2 low
		limit value			limit value
on	Underscale		ON (20mA)	ON (20mA)	
	Measured value	OFF (4mA)	Or	Or	OFF(4mA)
oFF	has dropped	Or	OUT1 high	OUT2 high	Or
O	below Indication	OUT1 low	limit value(*2)	limit value(*2)	OUT2 low
	range low limit	limit value	OFF(4mA)	OFF(4mA)	limit value
	value.		orOUT1 low	orOUT2 low	
	"' flashes.		limit value	limit value	

(\*1)This is only available for DC input and when OUT1 is DC current output type.

If OUT1 is not DC current output, the output status will be the same one as when

is selected during "Output status when input abnormal".

For manual control, the preset MV is outputted.

(\*2)Outputs a value between OFF (4mA) and ON (20mA) or between OUT1 (or OUT2) low limit value and OUT1 (or OUT2) high limit value, depending on deviation.

### Thermocouple, RTD input:

Input	Input range	Indication range	Control range
K, T	−199.9 to 400.0°C	−199.9 to 450.0 °C	−205.0 to 450.0 °C
	<b>–199.9 to 750.0</b> °F	<b>−199.9 to 850.0</b> °F	<b>–209.0 to 850.0</b> °F
Pt100	<b>−199.9 to 850.0</b> °C	−199.9 to 900.0 °C	−210.0 to 900.0 °C
	<b>−200 to 850</b> °C	–210 to 900 °C	<b>−210 to 900</b> °C
	<b>–199.9 to 999.9</b> °F	<b>–199.9 to 999.9</b> °F	<b>–211.0 to 1099.9</b> °F
	<b>–300 to 1500</b> °F	<b>–318 to 1600</b> °F	<b>–318 to 1600</b> °F
JPt100	<b>−199.9 to 500.0</b> °C	−199.9 to 550.0 °C	<b>−206.0 to 550.0</b> °C
	−200 to 500 °C	−207 to 550 °C	<b>−207 to 550</b> °C
	<b>–199.9 to 900.0</b> °F	<b>–199.9 to 999.9</b> °F	<b>–211.0 to 999.9</b> °F
	<b>–300 to 900</b> °F	<b>–312 to 1000</b> °F	<b>−312 to 1000</b> °F

## ADD

### บริษัท เอดีดี เฟอร์เนส จำกัด

### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพฯ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

### •DC input

Indication range: [Scaling low limit value – Scaling span x 1%] to [Scaling high

limit value + Scaling span x 10%]

However, if the input value is out of the range –1999 to 9999,

the PV display flashes " - - - " or " - - - - ".

**Control range** 

:[Scaling low limit value – Scaling span x 1%] to [Scaling high

limit value + Scaling span x 10%]

•DC input disconnection: When DC input is disconnected, PV display flashes

"--- " for 4 to 20mA DC and 1 to 5V DC inputs, and

"--- " for 0 to 1V DC input.

For 0 to 20mA DC, 0 to 5V DC and 0 to 10V DC inputs, the PV display indicates the value corresponding with 0mA or 0V  $^{\circ}$ 

input.

### [Burnout]

When the thermocouple or RTD input is burnt out, OUT1 is turned off (for DC current output type, OUT1 low limit value) and the PV display flashes " - - - "

### [Self-diagnosis]

The CPU is monitored by a watchdog timer, and when an abnormal status is found on the CPU, the controller is switched to warm-up status.

[Automatic cold junction temperature compensation] (Thermocouple input type) This detects the temperature at the connecting terminal between thermocouple and the instrument, and always maintains it at the same status as if the reference junction location temperature was at 0(32).

### [Power failure countermeasure]

The setting data is backed up in non-volatile IC memory.

### [Warm-up indication]

Thermocouple and RTD input: Sensor input characters and temperature unit are indicated in the PV Display, and the input range high limit value is indicated in the SV Display for approx. 3 seconds after the power is switched ON.

DC input: Sensor input characters are indicated in the PV Display, and scaling high limit value is indicated In the SV Display for approx. 3 seconds after the power is switched ON.

(However, if the scaling high limit value has been changed during the Scaling high limit setting, the changed value will be indicated In the SV Display.)

### [Auto/Manual control selection]

If "Auto/Manual control function" is selected during OUT/OFF Key function selection, automatic control can be switched to manual control and vice versa by pressing the ① (OUT/OFF Key) in the PV/SV display mode.

When the control action is changed from automatic to manual control and vice versa, the balanceless-bumpless function works to prevent sudden change of the MV.

When the control action is changed from automatic to manual control, the MV in the SV Display flashes.

The control can be performed manually by increasing or decreasing the MV with the  $\triangle$  or  $\nabla$  key.

(When the power supply to the instrument is turned on, automatic control starts.)

Accessories: Instruction manual :1 copy

Screw type mounting brackets: 1 set

CT (current transformer):

CTL-6S: 1 piece [when W(5A, 10A, 20A) option is added]

CTL-12-S36-10L1U: 1 piece [when W(50A) option is added] Terminal cover: JCR-33A: 1 piece (when the TC option is added)

JCD-33A: 2 pieces (when the TC option is added)

41

## บริษัท เอดีดี เฟอร์เนส จำกัด ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### 9.2 Optional specifications Alarm 2 (option code: A2)

When A2 action is set as Energized, the alarm action point is set by the  $\pm$  deviation from SV (except Process alarm).

When the input is out of the range, the output turns ON or OFF (in the case of High/Low limit range alarm).

When the alarm action is set as De-energized, the output acts conversely.

• When A2 option is added, one more option Heater burnout alarm or Heating/Cooling control can be added.

• If the A2 option and LA option are added together, they use common output terminals.

Setting accuracy: The same as the Indication accuracy

Action : ON/OFF action

Hysteresis : Thermocouple, RTD input: 0.1 to 100.0°C(°F)

DC current, voltage input: 1 to 1000

(The placement of the decimal point follows the selection)

Output : Relay contact, 1a

Control capacity: 3A 250V AC (resistive load)

Electrical life: 100,000 cycles

### Heater burnout alarm (option code: W)

Watches the heater current with CT (current transformer), and detects the heater burnout.

Heater burnout alarm is also activated when sensor is burnt out or when indication is overscale or underscale.

• When the Heater burnout alarm option is added, one more option A2 output or Heating/Cooling control can be added.

• This option cannot be added to DC current output type. Heater rated current: 5A, 10A, 20A, 50A, Must be specified. Setting accuracy: Within 5% of heater rated current

Action : ON/OFF action
Output : Relay contact, 1a

Control capacity: 3A 250V AC (resistive load)

Electrical life: 100,000 cycles

### Heating/Cooling control (option code: DR, DS, DA)

When the Heating/Cooling control option is added, one more option A2 output or

Heater burnout alarm can be added.

OUT2 proportional band : 0.0 to 10.0 times OUT1 proportional band

(ON/OFF control when set to 0.0)

OUT2 integral time : The same as that of OUT1
OUT2 derivative time : The same as that of OUT1

OUT2 proportional cycle: 1 to 120 seconds

Overlap band/Dead band:

Thermocouple, RTD input : -100.0 to 100.0°C(°F)

DC current, voltage input: -1000 to 1000

(The placement of the decimal point follows the selection.)

OUT2 ON/OFF hysteresis:

Thermocouple, RTD input: 0.1 to 100.0°C(°F)

DC current, voltage input: 1 to 1000

(The placement of the decimal point follows the selection.)

Output: Relay contact output, 1a

Control capacity: 3A 250V AC (resistive load)

1A 250V AC (inductive load cosØ=0.4)

Electrical life: 100,000 cycles Non-contact voltage output

12<sup>-</sup><sub>0</sub><sup>2</sup>V DC maximum 40mA (short circuit protected)

DC current output, 4 to 20mA DC, Load resistance: Maximum 550Ω



### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### OUT2 action mode selection function:

One cooling action can be selected by the keypad from the following.

Air cooling (Linear characteristic)

Oil cooling (1.5th power of the linear characteristic)

Water cooling (2nd power of the linear characteristic)

### Serial communication (option code: C5)

When this option is added, SV1/SV2 external selection function is disabled.

The following operations can be carried out from an external computer.

(1) Reading and setting of SV, PID values and various set values

(2) Reading of PV and action status (3) Function change

Communication line : EIA RS-485

Communication method: Half-duplex communication Synchronization method: Start-stop synchronization

Communication speed: 2400, 4800, 9600, 19200bps (Selectable by keypad)

Parity : Even, Odd, No parity (Selectable by keypad)
Stop bit : 1 and 2 (Selectable by keypad)Data format

### Data format

Communication protocol	Shinko protocol	Modbus ASCII	Modbus RTU
Start bit	1	1	1
Data bit	7	7	8
Parity	Even	Selection (Even)	Selection (No parity)
Stop bit	1	Selection (1)	Selection (1)

Data bit is automatically selected upon selecting the communication protocol.

( ): Basic set value

### Digital external setting:

Receives digital set value from Shinko programmable controller (with SVTC option). (It is necessary to set the Set value lock function to Lock 3 for the JCR and JCD.) When the SV data from Shinko programmable controller is outside of the SV high limit or SV low limit, the JCR or JCD ignores the value, and performs the control at the SV high limit or SV low limit.

### Loop break alarm (option code: LA)

Detects the breaking status on the loop such as heater burnout, sensor burnout or actuator trouble.

If LA option and A2 option are added together, they utilize common output terminals.

Setting range: Loop break alarm time: 0 to 200minutes

Loop break alarm span: 0 to  $150^{\circ}$ C(°F), 0.0 to  $150.0^{\circ}$ C(°F),

DC input: 0 to 1500 (The placement of the decimal point follows the selection.)

Output : Relay contact, 1a, Control capacity: 3A 250V AC (Resistive load)

Electrical life: 100,000 cycles

### Insulated power output (option code: P24)

Output voltage:  $24\pm3$ V DC (when load current is 30mA) Ripple voltage: Within 200mV (when load current is 30mA)

Maximum load current: 30mA

Color Black (option code: BK)

Front panel frame and case: Black

Terminal cover (option code: TC)

Electrical shock protection terminal cover

43



### **ADD FURNACE CO.,LTD.**

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

10. Troubleshooting
If any malfunctions occur, refer to the following items after checking the power is being supplied to the controller.



Turn the power supply to the instrument off before wiring or checking. Working on or touching the terminal with the power switched on may result in severe injury or death due to Electric Shock.

### 10.1 Indication

Problem	Presumed cause and solution
The PV display is	Control output OFF function is working.
indicating [ <i>□FF</i> □].	Press the () key (OUT/OFF Key) for approx. 1 second to
	release the function.
[] is flashing	The thermocouple, RTD and DC voltage (0 to 1V DC) input
in the PV Display.	may be burnt out.
	Replace each sensor.
	How to check whether the sensor is burnt out
	[Thermocouple]
	If the input terminals of the instrument are shorted, and if a
	value around room temperature is indicated, the instrument is
	likely to be operating normally, however, the sensor may be burnt out.
	[RTD]
	If approx. 100Ωresistance is connected to the input terminals
	between A-B of the instrument and between B-B is shorted,
	and if a value around 0(32) is indicated, the instrument is
	likely to be operating normally, however, the sensor may be
	burnt out.
	[DC voltage (0 to 1V DC)]
	If the input terminals of the instrument are shorted, and if a
	scaling low limit value is indicated, the instrument is likely to be
	operating normally, however, the signal wire may be
	disconnected.
	• Check whether the input terminal of thermocouple, RTD or DC
	voltage (0 to 1V DC) is securely mounted to the instrument terminal.
	Ensure that the sensor terminals are securely connected to the
	instrument input terminals.
I lie fleebing in	•
[] is flashing in the PV Display	• The input signal wire for DC voltage (1 to 5V DC) or DC current (4 to 20mA DC) may be disconnected.
the r v Display	Replace the input signal wire.
	How to check whether the input signal wire is disconnected
	[DC voltage (1 to 5V DC)]
	If the input to the input terminal of this controller is 1V DC and
	if a scaling low limit value is indicated, the controller is likely to
	be operating normally, however, the input signal wire may be
	disconnected.
	[DC current (4 to 20mA DC)]
	If the input to the input terminal of this controller is 4mA DC and
	a scaling low limit value is indicated, the controller is likely to
	be operating normally, however, the input signal wire may be
	disconnected.



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ช 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

<ul> <li>Check whether the input signal wire of DC voltage (1 to 5V DC) and DC current (4 to 20mA DC) is securely connected to the input terminal of this controller.         Ensure that they are wired properly.         • Check whether the polarity of thermocouple or compensating lead wire is correct.         • Check whether codes (A, B, B) of the RTD match with the controller terminal.         Ensure that they are wired properly.</li> <li>The PV display keeps indicating the value which was set during</li> <li>• Check whether the input signal wire for DC voltage (0 to 5V DC, 0 to 10V DC) or DC current (0 to 20mA DC) is disconnected.         How to check whether the input signal wire is disconnected</li> </ul>
indicating the value 0 to 10V DC) or DC current (0 to 20mA DC) is disconnected.
Scaling low limit setting.  [DC voltage (0 to 5V DC, 0 to 10V)]  If the input to the input terminal of this controller is 1V DC and if a value (converted value from scaling high, low limit setting) corresponding to 1V DC is indicated, the controller is likely to be operating normally, however, the input signal wire may be disconnected.  [DC current (0 to 20mA DC)]  If the input to the input terminal of this controller is 4mA DC, and if a value (converted value from scaling high, low limit setting) corresponding to 4mA DC is indicated, the controller is likely to be operating normally, however, the input signal wire may be disconnected.  • Check whether the input lead wire terminals for DC voltage (0 to 5V DC, 0 to 10V DC) or DC current (0 to 20mA DC) are securely connected to the instrument input terminals
The indication of the PV display is irregular or unstable  • Check whether the sensor input and temperature unit (or) are correct.  • Set the sensor input and the temperature unit properly.  • Sensor correcting value is unsuitable.  Set it to a suitable value.  • Check whether the specification of the sensor is correct.  • AC may be leaking into the sensor circuit.  Use an ungrounded type sensor.  • There may be equipment that interferes with or makes noise near the controller.  Keep the instrument clear of any potentially disruptive equipment
The PV display Internal memory is defective. flashes [Frr]. Please contact our agency or us.

### 10.2 Key operation

Problem	Presumed cause and solution
Settings (SV, P, I, D,	Set value lock (Lock 1 or Lock 2) is selected.
proportional cycle,	Release the lock selection.
alarm value, etc.) are	During AT or auto-reset.
impossible.	Cancel AT.
The values do not	Auto-reset ends in 4 minutes after starting.
change by the $  riangle $	
or ▽ key	



### ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: sales@add-furnace.com

Problem	Presumed cause and solution
The setting indication does not change within the input range even if the $\triangle$ or key is pressed, and new values are unable to be set.	SV high limit or SV low limit may be set at the point where the value does not change.  Set it to a suitable value while in Auxiliary function setting mode 1.

### 10.3 Control

Problem	Presumed cause and solution
PV (temperature)does not	The sensor is out of order.
rise	Replace the sensor.
	<ul> <li>Check whether sensor or control output terminals are securely</li> </ul>
	connected to the input or output terminals of the instrument.
	<ul> <li>Ensure that the wiring of sensor and control output terminals</li> </ul>
	are correct.
The control output	<ul> <li>OUT1 low limit value is set to 100% or higher in Auxiliary</li> </ul>
remains in an ON	function setting mode 2.
status.	Set it to a suitable value
The control output	OUT1 high limit value is set to 0% or less in Auxiliary function
remains in an OFF	setting mode 2.
status.	Set it to a suitable value.

For all other malfunctions, please make inquiries at our agency or us.

## 11. Character table

## Photocopiable material [Main setting mode]

Character	Setting item	Default value	Data
5	SV1	O°C	
52 III	SV2	O°C	

[Sub setting mode]

Character	Setting item	Default value	Data
RF III	AT/Auto-reset Perform/Cancel	AT/Auto-reset Cancel	
PIIII	OUT1 proportional band	<b>10</b> °C	
P_6	OUT2 proportional band	1.0 times	
<i>I</i> [[[]]]	Integral time	200 sec	
d	Derivative time	50 sec	
n III	ARW	50%	
c	OUT1 proportional cycle	30 sec, 3 sec	
c_b[]	OUT2 proportional cycle	30 sec, 3 sec	
R I	A1 value	O °C	
82:::::	A2 value	O °C	
H	Heater burnout alarm value	0.0A	
LP_r	Loop break alarm time	0 minutes	
LP_H	Loop break alarm span	O °C	



## บริษัท เอดีดี เฟอร์เนส จำกัด ADD FURNACE CO.,LTD.

44 ซอยบรมราชชนนี 70 ถนนบรมราชชนนี แขวงศาลาธรรมสพน์ เขตทวีวัฒนา กรุงเทพ ช 10170

โทร: 02-888-3472 โทร: ออกแบบ:08-08-170-170 แฟกซ์: 02-888-3258 https://www.add-furnace.com E-mail: <u>sales@add-furnace.com</u>

### [Auxiliary function setting mode 1]

Character	Setting item	Default value	Data
Lock	Set value lock	Unlock	
5 <i>H</i>	SV high limit	1370	
5L III	SV low limit	-200	
20	Sensor correction	0.0	
cñhL	Communication protocol	Shinko protocol	
cñno	Instrument number	0	
cāhP	Communication speed	9600bps	
cñPr	Parity	Even	
555F	Stop bit	1	

[Auxiliary function setting mode 2]

Character	Setting item	Default value	Data
۲ου	Input type	K: –200 to 1370°C	
SELH	Scaling high limit	9999	
45LL	Scaling low limit	<b>–1999</b>	
dP III	Decimal point place	No decimal point	
FILF	PV filter time constant	0.0 seconds	
oL H	OUT1 high limit	100%	
oLL[	OUT1 low limit	0%	
KS40	OUT1 ON/OFF hysteresis	1.0°C	
cRcr	OUT2 action mode	Air cooling	
oL Hb	OUT2 high limit	100%	
oLLb	OUT2 low limit	0%	
db	Overlap band/Dead band	0.0 °C	
XY56	OUT2 ON/OFF hysteresis	1.0 °C	
AL IF	A1 type	No alarm action	
AL 2F	A2 type	No alarm action	
8 ILA	A1 action Energized/De-energized	Energized	
R2LA	A2 action Energized/De-energized	Energized	
A IHY	A1 hysteresis	1.0 °C	
82XY	A2 hysteresis	1.0 °C	
8 183	A1 action delay timer	0 seconds	
8598	A2 action delay timer	0 seconds	
conf	Direct (Cooling)/Reverse (Heating)action	Reverse (Heating) action	
85_b	AT bias	<b>20</b> °C	
58 <sub>-</sub> 6	SVTC bias	0	
<b>५</b> 8□2	SV2 indication	Indication	
Eaur	Output status when input abnormal	Outputs OFF(4mA)or OUT1(OUT2) low limit value	
ñ8nU	OUT/OFF Key function	Control output OFF function	